

## Tas Version 9.5.0

### 64 Bit

All Tas applications have been updated from 32-bit to 64-bit. What this means is that the memory limit has been drastically improved and will allow for much bigger models to be created. This includes but is not limited to larger daylight calculations, larger thermal models and larger system models.

### Evolution

The following file types have evolved since 9.4.4:

- .T3D
- .TAI
- .TBD
- .TCD
- .TCR
- .TIC
- .TPD
- .TSD
- .TWD

### 3D Modeller

- Analysis model errors and warnings: Multiple selection is now available to set the “checked” flag.
- Movie or images showing the movement of the sun through one day now include the sun graphics if displayed in the current view.
- IDF files and DOE INP/IN files can now be imported into Tas3D through options in the “File” menu. See sections on IDF Wizard and DOE Importer below for more details.
- Windows style has been updated to modernised the look of the user interface.

### Building Simulator (TBD)

- TBD can now directly import weather data from EPW and TM2 files.
- Added an option to the simulation dialog that allows previously created zone groups in TSD files to be overwritten when merging into a TSD file.
- Windows style has been updated to modernised the look of the user interface.
- Glazing U Values can now be calculated using ISO 15099 methodology.

### Result Viewer (TSD)

- The Performance Summary now includes buttons which when clicked will take the user to a chart displaying the selected result for the related zone and day, with a relevant output filter.
- Windows style has been updated to modernised the look of the user interface.

### Systems (TPD)

- Plant room heating and cooling sources (Boiler, Chiller, CHP, etc.) now include losses from tanks and pipe loss components in capacity sizing (when doing so increases the sized value). Tank losses are included optionally – option is on by default.
- Windows style has been updated to modernised the look of the user interface.

### Tas Manager

- Right-clicking a folder in the treeview and selecting “Open in Explorer” will open the folder in Windows Explorer.
- Tas files can now be opened from the batch simulation dialog via the right-click menu.

## **Tas LEED Excel Plugin**

A new tool to automatically complete many of the fields in a Minimum Energy Performance Calculator spreadsheet for LEED v2009 or v4. The tool is a plugin which once installed can be launched from within Microsoft Excel. A completed 90.1 project with .NPO file is required in order to run the tool.

The current version of the tool is v1.0.0.0.

## **IDF Wizard**

- IDF files can now be imported directly into the Tas 3D Modeller. Three types of import are now possible :
  - TBD only: All data imported directly to TBD, as in previous versions of Tas.
  - Tas3D only: Geometry, zoning, and building elements imported to Tas3D.
  - Tas3D and TBD: Geometry, zoning, and building elements imported to Tas3D, constructions, internal conditions, and feature shades imported to TBD.
- IDF versions up to v9.1 now supported, exported IDF version is v9.1.

## **DOE Importer**

- INP and IN files can now be imported directly into the Tas 3D Modeller. Three types of import are now possible :
  - TBD only: All data imported directly to TBD, as in previous versions of Tas.
  - Tas3D only: Geometry, zoning, and building elements imported to Tas3D.
  - Tas3D and TBD: Geometry, zoning, and building elements imported to Tas3D, constructions, internal conditions, and feature shades imported to TBD.

## **Design Day Wizard**

- Heating and cooling design days can be created using the 2017 ASHRAE Weather Data.

## **Climate Based Daylight Modelling**

- LEED Option 2 report has been updated.
- Tas Worker Peer tray app no longer runs on start-up by default after installing.
- Live search in zones filter list to make it easier to include/exclude zones.

## Further Details

### 3D Modeller: Details

- Façade length calculation is now correct for spaces spanning more than one floor if the space on the lower floor has no exposed surfaces.
- The sun graphics now move in a movie according to the sun position.
- Closing a file with the Drawings settings dialog open no longer causes a crash
- A shade not fitting into an internal <null> wall was not being reported as an error if the adjoining spaces were in the same zone.
- A window with a Full Height placement that is placed in a wall with no height no longer causes a crash in shading calculations.
- It is now possible to place a group window if the spaces on either side of the wall are different heights. Child windows in the analysis model are positioned in the lower or upper section of the wall.
- A window with a Door placement was not being positioned on the floor if the floor was not at storey level.
- Overlapping walls in a floor plan could cause a crash in shading calculation
- Shading calculations could be initiated even when not requested. This is now fixed.
- Incorrect internal surfaces of a space could be calculated when the ceiling internal surface was below the floor internal surface.
- The Imported Drawing Settings dialog is now tabbed with the 3D shades import options on a separate tab. This reduces the height of the dialog which had caused problems on some screens.

#### The following changes apply to gbXml imported models only

1. Editing a gbXml imported window that has no height was causing a crash when the Type/Dimensions dialog closed.
2. Building Element thicknesses option for imported models is now applied to a non-analysis 3D view when the Tools option is selected rather than only with the View Refresh toolbar button.
3. Creating Floor plans from an imported model now checks if spaces are all at one level and on the storey level. A warning is given if not and requests confirmation to continue.
4. gbXml import now allows for an Opening Type to have no frame width
5. For an imported model, if building element thicknesses are not used then window frames are drawn with no depth and no wall sides are drawn.
6. A gbXml surface with inconsistent surface angles (the defined polygon not matching the tilt and azimuth angles) may have been incorrectly reversed when imported. It is now only reversed if both angles are opposite
7. The volume calculation for a space now allows for nearly vertical surfaces which may have caused an incorrect value.
8. A warning is now given if the volume imported from a gbXml file does not correspond to a calculated value for the space. The volume in the gbXml file should be the internal volume of the space and is used when Building Element thicknesses are not used or a space has other warnings.
9. A warning is no longer given for surfaces with a zero thickness Building Element.

### Building Simulator (TBD): Details

- Presimulation checks:
  - New: Bad cloud cover in weather file
  - Fix for false positives in check for split zones
  - New: Check 1 building element is not assigned to multiple substitute elements.
- Added automation function to Building to get building element by name.

**Systems (TPD): Details**

- Ctrl+C and Ctrl+V shortcuts can now be used in component profiles.
- Multichiller is now correctly displayed as a multiplier and not a percentage – this was a display issue only.
- New simulation events:
  - Fluid temperature falling below absolute zero
  - No pumps attached to a collection
- Maximum and minimum signals from a controller can now be obtained through Lua code.

**IDF Wizard: Details**

- Correction for the orientation of exposed floors in imported models, this may affect results.
- Fix for region-specific comma/full stop issues on the main form.
- Better handling of impossible window U-values.
- Fix for rare issue where an internal wall could be absent after import into Tas.

**DOE Importer: Details**

- Improved the algorithm for correcting inconsistent roof and floor geometry.
- Fix for doors receiving the wrong building element and construction in import to TBD.
- Fix for a crash which occurred when switching between TWD files.
- Fix for failure to load pane data from library.
- A surface linking to its own space is now treated as adiabatic rather than causing an error.
- Now works with “frac/design” type schedules – a value of 1 is assumed in place of “-999”.
- Now recognises a wider range of keywords.

**Design Day Wizard: Details**

- User is now notified by the design day wizard if it is going to delete previously setup design days.

**Report Generator: Details**

- Fix an issue with the Annual Loads report where the Heating label in the graph legend was not displaying correctly.
- Correction for BB101 report as it was incorrectly displaying an error when the future London weather data was used.

**UKBR Studio (2013): Details**

- Notify users when V3.5 (2006) and V4.1.4 (2010) NCM Activities are loaded into the 2013 studio.
  - Description of Mixed Mode system tweaked to provide more clarity.
-

## **Tas Version 9.4.4**

### **Building Simulator (TBD)**

- Fix for a bug introduced in 9.4.3 which meant models with certain IZAM setups would fail to simulate.

### **Systems (TPD)**

- New flow sizing options to use the ventilation gain profile from zone internal condition (peak or hourly). Existing "Internal Condition" options renamed "IC – Outside Air".
- Fix for a rare sizing bug in coils and humidifiers which could lead to sized capacity being incorrectly set to zero.
- Fix for a rare sizing bug in coils and humidifiers which could lead to sized capacity becoming too large and causing an error in the sizing run.

### **Report Generator**

- New report added for the new 2018 BB101 regulations.

### **Climate Based Daylight Modelling**

- Automatic weather calibration for all weather files
- Added LEED Option 2 calculation methodology
- Timestep used for interpolation can be changed & sub-hourly start and end times are now available.

### **Ambiens**

- Ambiens files (.tai) are now compressed so they take up less memory
- The zoom using the mouse wheel now zooms on the mouse location not the centre of the screen as it previously did.

### **90.1 Studio**

- Baseline geometry wizard produces 2007, 2010, 2013 and 2016 models.
- Baseline lighting wizard has space type and building type options for 2007, 2010, 2013 and 2016.
- 90.1 baseline constructions databases updated.

## Further Details

### Systems (TPD): Details

- Users can now navigate around the schematic view using the keyboard arrow keys to pan and number pad plus and minus keys to zoom in and out.
- Zone components (fancoil, etc.) were not being included in the check for whether zone design flow or fresh air rate were in use. Fixed.
- Fix for an unrecoverable error during simulation caused by an internal condition having a metabolic rate of zero when sizing the flow rate upon occupancy.
- Unit corrections:
  - Temperature tolerance in options dialog is a temperature range.
  - Minimum fresh air controller band is a percentage.
  - When using US units the correct unit will now be displayed for component capacities (gpm/sqrt(psi)).
- It is now possible to have 365 days of preconditioning. The limit had previously been 364.
- Added info message for a plant collection containing no loads.
- Added zone name to label builder for zone.
- Fix for application crashes that result from utilisation of active accessibility.
- Heating Coil maximum off-coil temperature profile can now use control signal as a variable.
- Reduced rounding error which was present in some results series when viewing annual sum or average results with large values.

### Building Simulator (TBD): Details

- When closing the Design Day Wizard, if the TBD file was looking at an internal condition in some cases the TBD file would crash. Fixed.
- New pre simulation check for shading data longitude/latitude mismatch.
- New automation functions:
  - Building elements – get feature shade and remove feature shade.
  - Building – get zone from a given name.
- Pre simulation checks for BB101 updated to match up with the new 2018 regulations.
- Bug fixed where entering 0 or 1 in to the schedule name box would cause unusual behaviour.
- Bug fixed on the calendar grid where you could change the row headers by double clicking to the right of the grid.
- Added keyboard shortcuts for copy and paste in the weather grids.
- Fix for a bug in the weather grid where you couldn't use backspace or enter.

### 3D Modeller: Details

- New automation functions for file export including options zone groups for tags and zone sets for storeys.
- Importing 3D polygons from a DWG file for shading purposes has been improved to retain original meshes of triangles (rather than breaking down to individual triangles) and building elements are now created according to layer names in the DWG file. This allows better selection of meshes of triangles for assignment of a building element, deletion etc, provides a performance improvement and results in smaller model files. To enable easier z mapping for gbXml models note that the minimum and maximum z co-ordinate of a surface is indicated in the Surface Properties of a selected surface.
- New option for a "simple" shadows view in Daylight View Settings dialog. This option was provided by default previously e.g. when changing the sun position and has been added to give better control to switch between a reflected light view and a simple shaded view. Note that this view can be controlled also via the standard Sun Position dialog rather than using the Daylight View Settings dialog. Also the shadows on/off button can also be applied.

- The view definition of a current 3D view is used when creating a daylight view.
- Display of daylight results in plan now shows any zone name or drawing through the fill mode results. This is dependent on the “Transparent Fill” option in the View/Show 2D Zones menu.
- Fix to selection of daylight calculation to display via the option Display Results on Plan. Previously the most recent calculation was always displayed. Using this option from a Results dialog will now display its results by default.
- Fix for ensuring an analysis model error that indicates a window or shade has been omitted, as it does not fit in a wall, is always reported.
- Fix for daylight calculations that included a very small amount of light leakage into a room with some geometry configurations.
- Fix for a crash when omitting external zones and creating zone sets for each storey on export.
- The north angle for a building is always adjusted to be a whole number. It was possible to type in a number with a decimal part which was not shown in the dialog but which then caused simulation errors.
- Now checks for area of ghost elements when determining if adjacent spaces would be external (and require an external zone). For example thin slivers of ghost elements can be created when floors are not aligned exactly and spaces incorrectly set to be external. The check is for an area less than the smallest area that can be exported for analysis which is set to 0.05 m2.
- Fix to shading calculations when using AMD FirePro graphics cards and additional checks on initialization that graphics cards have the required functionality.
- Fix to shading calculations when combining results for multiple surfaces of an external zone when the sun falls on the “inside” of one of the surfaces.
- Fix to shading calculations when gaps occur in the outside envelope of a building – usually caused when modelling external spaces and using a ghost element.
- Fix to crash when selecting/deselecting spaces in a 3D view.
- Fix for placing a window in a wall. A window can now always be placed within the full length of a wall.
- Fix for placing a window in a roof. A window can now always be placed within the full area of the space.
- Fix for daylight calculations where there is an external space with a transparent surface or window where the space is non-zoned or not included in the calculations. The calculations now allow light through the transparent surface into the space and through to adjacent spaces.
- Fix for setting zones to be included in daylight calculation when a daylight view has been created before zones assigned.
- When using the option to “Omit reflectance from external surfaces from calculation” for daylight calculations, surfaces adjacent to external spaces are now omitted unless the space is zoned.
- Fix to a crash when opening a file with a saved Plan 3D Analysis window.
- Fix to releasing the cursor focus after setting the view for a 3D window from a Plan 3D Analysis window.
- Fix to the calculation of the volume of a gbXml imported space when there are overlapping surfaces and the option is set to “Use building element thicknesses”. A model warning is added to indicate that the original volume provided in the gbXml file is used instead.
- Fix for a crash when using ctrl H to display a DWG file in a plan view when no walls have yet been created.
- Update for gbXml schema 6.01 – import now accepts an ExposedFloor surface type.

### **SAP Geometry Tool: Details**

- Fix for a crash during the export to a JPA Designer XML if the dwelling contains no windows.
- Reclassified some impossible bridges as “unrecognised”.
- Fix for exporting dwelling images on some machines.
- Fix for a crash that could occur when building element names contained certain punctuation.

### **Results Viewer (TSD): Details**

- New automation functions to get zone data from a given zone name.
- Fix for a bug with the tree view which caused error messages to appear when clicking on a new item in the view.
- Bug fix for the grids not resizing properly with the rest of the application.

### **IDF Wizard: Details**

- Support for WindowMaterial:SimpleGlazingSystem.
- Fix for bug in import where incorrect equipment radiant proportion would be used in some circumstances.
- Fix for some day schedule import bugs.
- Additional checks and fixes when importing shading data from a CSV file.

### **TM59 Wizard: Details**

- All TSD files now produced by the wizard now store aperture data.
- Added the ability to filter by string on the Gains Setup page.

### **Design Day Wizard: Details**

- Fixed a minor typo on the Cooling Design Day Zone Setup page (ot -> to).

### **UKBR Studio (2013): Details**

- Importing TBD files into the studio has been sped up when surface output specifications are applied to multiple surfaces.
- Improved the error notifying the user that an invalid construction has been applied to a building element in the source TBD file.

### **Daylight Analysis Results Viewer: Details**

- Lit Area % fields added to the Daylight Distribution report for the proposed and existing buildings.

### **90.1 Studio: Details**

- The 90.1 Studio is now a single instance application.
- Added new project status messages and changed the order in which some of them appear.
- The generated baseline TBD files now include zone sets for each storey (when able to re-export Tas3D geometry).
- TPD batch simulate now ensures that the main simulation period is included even if it had been unticked manually in the systems file(s).

### **Systems Wizard (TPDx): Details**

- In VAV systems with pressure reset the control band on the minimum fresh air controllers has been increased from 1% to 2%. This was done to increase system stability and reduce simulation time.
- Fix for a crash that could occur when reusing a tpdx2013 file containing baseline system 11.
- Unit fix: Reset temperature increase is a temperature range.

**IC Generation Tool: Details**

- Fixes for pollutant by volume.

**Passivent Tool: Details**

- Fix for crash with missing weather file.

**90.1 Airside Efficiency Tool: Details**

- “Optimiser” renamed “Economiser”.

**Climate Based Daylight Modelling: Details**

- Previously, non-CIBSE weather files required manual calibration. This process has now been automated, with a built-in check to help identify potentially unsuitable weather files.
- LEED option 2 CBDM daylighting methodology has been added along with an appropriate report.
- Variable timestep used for interpolation & sub-hourly start and end times have been added to the CBDM wizard.
- User can change how much of the CPU is utilised on machines with multiple cores when performing local CBDM calculations.
- Wording: DA has been changed to sDA on CBDM report.

**Documentation: Details**

- Updates for TPDx NPO guide.
-

## **Tas Version 9.4.3**

### **Building Simulator (TBD)**

- A new option in the tools menu to delete unused items from the TBD file (constructions, schedules, feature shades, etc.). A dialog allows the user to specify the types of unused items to remove.

### **3D Visualisation (Building Simulator and Results Viewer)**

- New camera position dialog. Assists custom camera positioning (e.g. to get similar views of two models for comparison).

### **UKBR Studio (2013)**

- Updated the studio to account for the March 2018 update to the Welsh 2014 NCM Modelling guide.
- Updated the studio to account for the March 2018 update to the Scottish 2015 NCM Modelling guide.

## Further Details

### 3D Modeller: Details

- Evolution for t3d file created from an imported gbXml file was not always successful – now fixed.
- Using undo following a DWG import could cause a crash – this is now fixed.
- Fix to shade creation – dialog was not retaining the fin spacing option between edits and using this option failed via automation.
- When using undo an incorrect floor was being shown in a 2D plan view if multi-select was disabled for the view. This is now fixed.
- The incorrect volume was displayed in the Imported Space Properties dialog for a gbXml imported space if it had gaps when building element widths were not applied i.e. the volume shown should be as imported from the gbXml file and which was exported to TBD.
- The calculation for the volume of a space has been improved to allow for numerical inaccuracies that may arise.
- Better detection for imported spaces with surfaces that may have an incorrect orientation. Previously these spaces may have been reported as only having gaps.

### Building Simulator (TBD): Details

- Simulating a TBD file which does not include applied IZAMs and merging with a TSD file which does include IZAM data causes a crash and the TSD file to become unusable. Fixed.
- Made zero an invalid efficacy in the lighting function dialog. Setting an efficacy of zero would stop the file from being simulated.

### Systems (TPD): Details

- Added a message for situations where a flow rate or fresh air rate specified in a zone is not in use by any components in the system.
- Added a message for very low minimum flow rate in flow components - can cause failures to converge with some controllers.
- Added checks for bad profiles for DXCoilUnit, Fan, and FanCoilUnit.
- New icon for Water To Water Heat Pump.
- Ensure that saved library files include the correct file extension.

### Systems Wizard (TPDx): Details

- When renaming a design condition, the name in the treeview now updates simultaneously.
- Updated the Microsoft.ReportViewer reference to use the 2015 Microsoft Reporting Services pack. Was still using the 2008 unintentionally.

### UKBR Studio (2013): Details

- Updated the Microsoft.ReportViewer reference to use the 2015 Microsoft Reporting Services pack. Was still using the 2008 unintentionally.

**IDF Wizard: Details**

- Fix for a bug which meant "Schedule:Compact" objects were being imported incorrectly, leading to incorrect schedules in TBD internal conditions.
- Exported IDF version updated to v8.9.
- Added tooltips to the form.
- Improved export speed for TBD files containing large numbers of zones and internal conditions.
- Building element types are assigned to building elements created during import.
- During import zone groups are created corresponding to Zone Lists in the IDF file.
- "Foundation" boundary condition treated as a ground link during import.
- Fixed some errors which occurred when encountering unexpected inputs in the IDF file.

**DOE Importer: Details**

- Added tooltips to the form.
- Building element types are assigned to building elements created during import.

**Report Generator: Details**

- Fixed for an issue where the Peak Loads and Peak Loads Comparison reports would double count the simultaneous peak load when the report was run from TSD. This double counting would not occur if report generator is opened through Tas Manager.
-

## Tas Version 9.4.2

### Evolution

- The TPD file type has evolved since 9.4.1.
- The T3D file has evolved if it contains an analysis model with errors or warnings. It is not always possible to evolve the list of errors and warnings and instead the user is instructed to recreate the analysis model to get them.

### General

- The Tas installation now includes an Australian weather TWD file in the databases folder.

### 3D Modeller

- The Errors and Warnings dialog now has a “Checked” column and an option to display those “checked” or not. There is also an option to select the wall/space/construction of the error – if the current view is 3D, it needs to be a non-analysis view. Note that the entity is not “highlighted” if it is selected. For a gbXml model, there is an option to Zoom to the single zone of the error – this modifies the current 3D view to display just one zone.
- It is now possible to set the Building Element for imported shade surfaces (from a gbXml import or a DWG 3D import). This allows material properties to be applied for daylight calculations.
- AutoCAD 2018 DWG/DXF drawings can now be imported.
- A 3D view of 3D polygonal geometry is optionally displayed when opening a DWG/DXF file.
- “Select by Rectangle” is now available in a 3D view. For example, this makes it easy to select all walls on an elevation.
- There is now an option “Keep Reverse Surface Settings” on the gbXml import dialog. This is available when merging a gbXml file into an existing model and will reverse any surfaces that have previously been reversed either via the “Reverse Geometry” option for a selected wall etc. or automatically via the “Reverse Incorrect Orientation Surfaces” option.
- A reference to a “Null” surface type has been changed to “adiabatic”.
- There is now an option “Set Adiabatic” for selected imported constructions. This can be used for surfaces that should not be analysed as “Exposed” as they are adjacent to a building that has not been included in the 3D model.
- A DWG/DXF file can be imported into a gbXml created model. This allows shading surfaces to be created from a drawing file exported from Revit of geometry that is not included in the gbXml file e.g. shade systems.
- For imported spaces that are reported as having gaps, an estimate of the area of the gap is now given in the Errors and Warnings dialog when possible.
- There are now options for a selected imported floors or roofs to set the “Offset Thickness Direction” as centred, up or down.
- The Select All and Select by Rectangle options are now available for walls and spaces on a 2D floor generated from a gbXml import.

### Building Simulator (TBD)

- Summaries report now displays total floor area and volume per zone group.
- Aperture function dialog: If a function was chosen evaluating to ZDCCM, if pollutant was disabled using the checkbox, behind the scenes the pollutant setpoints would be high, meaning that the apertures would never open. Fixed.

### **New TM59 Wizard**

- Launches from TBD Tools menu.
- Takes inputs from the user to perform a TM59 assessment.
- Can produce and simulate multiple scenarios, producing a report for each scenario.

### **SAP Geometry Tool**

- New option to export XMLs for use in the JPA Designer software. Note that information on internal ceilings and floors, as well as exposed floors, is not included in this export and users should complete missing data using information from the Excel sheet.

### **Results Viewer (TSD)**

- TSD reports can now be created from within TSD using the new toolbar button.

### **Systems (TPD)**

- Fix for a flow rate issue which affected waterside systems where heating and cooling groups using variable control capacity were present in systems with pumps which were not using controllers. The issue resulted in incorrect flow rates and delta T values across the heating and cooling groups in these situations. Fixed. UKBR Studio projects were not affected.
- Zone component (radiator, fancoil, etc.) heating and cooling can now be sized with "Simulation Data", which uses the peak loads calculated in the TBD simulation.
- Added a "builder" button to labels which shows a list of results which can be added to the label. For example, heating load can be added to a heating coil and the value displayed will change according to the hour selected for display.
- Optional condensation result added for cooling coil, DX coil, fancoil unit, and DX coil unit.
- Steam humidifier supply water temperature can now be set as equal to simulation external water temperature.
- Size factors can now be specified for Heating and Cooling groups, for use in oversized primary-secondary systems.
- Zoom in and zoom out buttons have been added to the toolbar.
- The result graphs now report electrical loads in W or W/ft<sup>2</sup> when the unit system is set to US-Customary.

### **Systems Wizard (TPDx)**

- Support added for 90.1-2016 methodology.
- Baseline systems 9 and 10 have been changed to single-zone systems.
- Multi-zone non-UKBR systems include the "Simulation Data" sizing condition by default in the zone component heating and cooling.
- Changes for 90-1 heating pumps for better compliance with 90.1 section G3.1.3.5.
- Changes for 90-1 cooling pumps for better compliance with 90.1 sections G3.1.3.10 and G3.1.3.11.

### **90.1 Efficiency Tools**

- Support added for 90.1-2016 methodology.
- Support added for 90.1 G3.1.3.1 (electric heating for heat pumps in cold weather).
- Heat pump heating efficiencies were incorrect in older versions because the wrong variables were being used to determine efficiencies during simulation. Fixed.

### **UKBR Studio (2013)**

- Manual lighting gain function was being generated slightly incorrectly: Minimum lux depended on backspace sensor, which should not affect manual control (and could not be edited). Now it correctly uses minimum percentage gain.
- Updated the studio to account for the November 2017 update to the English 2013 NCM Modelling guide.

- The default CO<sub>2</sub> factor for district heating has been increased to 0.19, due to change in the notional buildings CO<sub>2</sub> factor in the November 2017 update to the English 2013 NCM Modelling guide.
- Fixed an issue where the Scottish Notional building was using the incorrect fuel source (fuel oil) when the actual was using direct electric. Now uses grid supplied electricity as per the Scottish NCM modelling guide.

### **UKBR Studio (2010)**

- Fixed a bug with the setup of CHP systems which meant the CHP was under-contributing to heating and Domestic Hot Water. UKBR 2013 projects are not affected.
- Changes for systems generated by Northern Irish projects, made for software validation. If projects created in older versions of Tas are now re-run then results will change. These changes only apply to Northern Irish 2010 projects – other UKBR projects are not affected.

### **3D Visualisation (Building Simulator and Results Viewer)**

- Annual insolation display will now only display values for exposed, non-null surfaces. Results previously shown for other surfaces (e.g. those linking to an external zone) were misleading, and did not relate to actual solar gain calculations. This did not affect any result data. Fixed.

### **IC Generation Tool**

- The tool now has the option to import only the zones from a selected zone group.

### **90.1 Studio**

- The building element assignment page of the baseline generation wizard now displays the Tas building element types, as a reference for the user.
- The reports produced by the studio now report electrical loads in W or W/ft<sup>2</sup> when the unit system is set to US-Customary.
- Fixed a bug where presimulation days in TPD design conditions would crash the studio.

### **IDF Wizard**

- Surface shading data can now be imported from EnergyPlus CSV files. Note that the shading data will only be valid for TBD files using the same weather data that was used for the calculations (EPW weather can be imported by the IDF Wizard). To create the shading data the IDF file must include a ShadowCalculation object.
- Export to IDF now creates an IdealLoadsAirSystem for each zone, allowing immediate simulation in EnergyPlus.
- Export to IDF approximates null surfaces with InfraredTransparent materials.
- Ground temperature now included in export to IDF.
- Now includes the option to automatically open the newly created TBD file after a successful import.
- People (i.e. occupancy) sensible heat fraction now always uses the “autocalculate” option unless a value is specified in the IDF file.

### **DOE Importer**

- The additional materials which were supposed to be included in the library in v9.4.1 have now been included.
- Now includes the option to automatically open the newly created TBD file after a successful import.

## **Climate Based Daylight Modelling**

- Weather calibration is only shown for non-CIBSE weather
- Tas Peer to Peer communication is now encrypted with an encryption key
- When distributing calculations, T3D files can be streamed to the workers rather than relying on a shared network directory
- Intermediate CBDM data can be saved for detailed analysis in the **new CBDM Results Viewer**. The file extension is '.tcbdm'. This results viewer makes it easier to demonstrate HEA01 BREEAM compliance and export annual hourly lux results. Also allows for changing the UDI thresholds after the calculation has been performed, and changing the weather providing the longitude and latitude are the same.
- CBDM calculations can now be performed locally without relying on any networking infrastructure.

## **Tas General Optimisation**

- New utility to assist in performing advanced optimisation tasks and parametric simulations.

## **Daylight Analysis Results Viewer**

- New daylight analysis results viewer for viewing and generating reports associated with the daylight analysis wizard.
- Can produce contour drawings.

## **Report Generator**

- A new report has been added for the draft BB101 regulations. The report currently uses the criteria in the January 2017 final draft document.

## Further Details

### 3D Modeller: Details

- A reference to a “Null” surface type has been changed to “adiabatic”.
- When using tags, upon export, if merging with an existing TBD file, a zone could appear multiple times within a zone group. This had no effect other than looking strange. Fixed.
- When creating a window group, entries that were marked as ‘door’ or ‘full wall height’ would sometimes be flagged as overlapping other entries even when they were not. Fixed.
- Nested group windows were being incorrectly reported as overlapping.
- A fix has been made to prevent a crash when the “Mirror” option is used for a window group and a window in the group was currently selected.
- In daylighting, unused zones are no longer present in the list of zones to select.
- Vertical Sky Component calculation did not always include a window adjacent to an external zone and has now been fixed.
- A fix has been made to prevent a crash when opening a file if previously a building element had been deleted for which daylight material properties were specified.
- When importing an image file (e.g. .jpg) to a file that includes no drawings (.dwg or .dxf files), it would not be displayed and many functions were inaccessible (including drawing walls and so on) until the user closed the 3D Modeller. Fixed.
- The drawings sidebar would not allow the user to fix the path of a drawing. Fixed.
- When attempting to export an image or animation, some users would receive the error “Unable to create animation – Error creating offscreen bitmap in OpenGL”. Fixed.
- Displays an error message to indicate when picking in a 3D window is not available. This usually occurs with a remote login and is caused by using an old version of OpenGL (Framebuffer Object is not supported).
- A fix has been made to prevent a crash when selecting multiple planes in the Edit Planes dialog.
- After importing a gbXML file without merging, the view would appear blank. Fixed.
- A fix has been made to prevent a crash when importing a gbXML file generated by Revit that has an “opening” of type Air placed in a floor surface – this can occur when exporting from Revit if spaces have gaps between the surfaces.
- gbXML import allows for a gbXML space to reference a storey that is not defined.
- A t3d file created from a gbXML import via automation can now be opened in the 3D Modeller.
- When “Using Building Element Thicknesses”, the volume of a space was being incorrectly calculated sometimes if an imported gbXML model is positioned a long way from the origin.

### Systems (TPD): Details

- When viewing component properties multiple undo points were being incorrectly created for profile data changes even when no changes were made. Fixed. This change will make undo and redo behaviour smoother.
- Added a warning for a control band of zero on an airside controller, which can lead to unpredictable behaviour. EDSL advise that a small non-zero value (e.g. 0.001) is used instead of zero.
- Added a plantroom simulation event for occasions when a fluid is cooled below its freezing point.
- Fix for a bug where air could enter a steam humidifier at 100% RH and leave at over 100% RH.
- Some results graphs were displaying incorrect values when the user’s unit preferences were set to use Btu (i.e. using American-style I-P units). Fixed.
- Passthrough controller schematic symbol is now an arrow.
- Difference controller schematic symbol is now a minus sign.

- Outdoor controller schematic symbol is now blue.
- Outdoor controllers no longer have sensor or chain ports.
- PV panel power temperature coefficient is now zero by default. For those users who wish to use this feature, -0.5 %/°C is a typical value.
- PV panel temperature has been added to the component's result table.
- When a PV panel was using a zone surface and also using the power temperature coefficient, the external temperature used to calculate panel temperature was incorrect. Fixed. This did not affect results for panels using "specify values" or panels with a power temperature coefficient of zero.
- Changed the images used for dry cooler, horizontal GHE, and slinky coil when these components are rotated.
- Renamed airside exchanger "consumption" result to "load".
- Changed the grid spacing for controller profile graphs. They will now adjust to make profiles much more readable when small flows are involved.
- Added warnings for bad water supply temperatures into the steam humidifier.
- System multiplicity is now displayed next to the system name in the treeview.
- Component ports are now coloured blue when not connected to a duct or pipe.
- Fan minimum flow rate now only checked when the fan is linked to a controller (in some cases fans where controllers had been removed could no longer be simulated – fixed).
- Added a simulation event for plantroom collections which use the variable capacity option but which have not been sized.
- If a component with an empty table modifier was copied then the copy operation would fail. Fixed.

#### **Building Simulator (TBD): Details**

- New presimulation checks:
  - A zone for which all the surfaces are adiabatic
  - Surface link errors
  - Internal surface link errors
  - Bad value for Domestic Hot Water demand
  - Feature shade on a horizontal surface
- The pre-simulation check which checks for overlapping thermostat\humidistat limits now accounts for schedules.
- An additional space has been added to the pre-simulation check for a bad construction, to stop the construction name merging with the word before.
- When adjusting the Additional Heat Transfer for a construction, the U-value updates when the user clicks away from the Additional Heat Transfer box. Previously it was necessary to navigate away from the construction and return in order to update the U-value. Improved the presimulation check for a zone split into different areas of the building – previously, some instances of this issue were being missed by the check.
- Zone groups created through automation (which mainly happens through export from the 3D Modeller using tags) are henceforth no longer read-only. Such zone groups in existing files will remain unchanged.
- When exporting and merging from the 3D Modeller, the TBD file containing unused surface output specifications would cause unnecessary delay. Fixed.
- A reference to a "null-link" surface has been changed to refer to an "adiabatic" surface.
- Internal condition profile graphs have been visually updated.
- Condensation rate and vapour pressure graphs have visually updated for all constructions.
- Corrected a bug which meant that the area of internal surfaces could be double counted in the building elements list view. This was a display issue only and did not affect simulation.
- When the "Significant radiation when sun below horizon" message relates to a design day, this is now stated in the message text.

- Fix for an issue where some adiabatic surfaces were not included when calculating the reported building element surface area in the HTML Summary.
- The wind rose charts now update when the weather data is changed.
- Link errors were generated incorrectly, in particular for shades with a surrounding frame. Now fixed.
- Updated the tab controls.
- Updated the list box and selection buttons for the design days and calendars.
- Updated the grids for the schedules, constructions, materials and the surface output specification pages.

#### **Results Viewer (TSD): Details**

- When exporting results to a CSV, the exported values for design day weather were incorrect. Fixed.
- Fixed an issue where TSD would crash if a performance summary was produced for a heating or cooling design day.
- Updated the tabs.
- Updated the grid in the output filter page.
- Fixed an issue where sometimes the graph legend would not match up the data point styling on the graph.
- Stop the surface number from appearing when looking at a tabular sum of surface data for a zone.

#### **UKBR Studio (2013): Details**

- Input summary now shows the current weighted air permeability, rather than an unused value. This was a display issue only. Fixed.
- Zones with daylighting strategies that differed only in having a backspace sensor (with all other options the same) would be given the same internal condition, and so some zones would have an incorrect backspace sensor setting for their lighting control. Fixed.
- An improved warning message will appear if the number of runs in the studio file stops the file from being saved.
- Added a check in the Criterion 3 solar gain check which would stop surfaces smaller than 100mm from being double counted.

#### **IC Generation Tool: Details**

- Fixes for instability experienced when changing display settings while using the tool.
- The appearance of the data grid has been altered to assist copy and pasting.

#### **Lighting Control Tool: Details**

- In the descriptions of the functions values are now displayed in the correct places. This issue only affected the display and not the behaviour of the functions.
- The appearance of the data grid has been altered to assist copy and pasting.

#### **IDF Wizard: Details**

- References to “null links” have been changed to “adiabatic links”.
- When exporting an IDF from TBD, the log file will now note any fenestration surfaces with more than four vertices.
- Exported IDF version updated to v8.8.
- Export stops if a surface link error is encountered.
- Export would encounter an error if the internal conditions included lighting functions. Fixed.
- Fixes to avoid exporting an adiabatic glass wall to IDF.
- Minor changes made to the comment types exported into IDF. This affects which comments are still visible in the IDF after editing in other programs.

- When exporting to IDF thick material layers (over 0.5m) are now split into multiple layers as they tended to prevent simulation in EnergyPlus (particularly soil layers in ground floor constructions).
- When importing IDF, surfaces using OtherSideConditionsModel and OtherSideCoefficients are now treated as external if exposed to sun or wind and adiabatic in all other cases.
- When importing IDF, if a volume of zero was specified for a zone it will now be calculated from the floor area and room height.
- Fix for creating internal window geometry when importing IDF.
- Internal windows and doors are removed during export to IDF.
- Support for InfraredTransparent materials in import – converted into null surfaces.
- Fix for a rare surface geometry export bug which could prevent export to IDF.

#### **DOE Importer: Details**

- The “PROJECT-DATA” keyword no longer prevents file import.
- The main window can now be resized and the content will scale with it for better visibility on high-resolution screens.
- Fix for a bug which would incorrectly import the name of a door’s construction.
- Import cancelled if a surface links to the same space on each side.
- If a glass type code has been specified which seems incorrect a revised code will be guessed from the number of panes (this mostly applies to .IN files).

#### **Tas Manager: Details**

- Directories could not be set if the registry keys did not already exist – e.g. for a user other than the one who installed Tas. Fixed.
- When viewing Tas file versions via the Tas Manager, some version strings have been made more explicit, e.g. “v9.4.0” instead of “v9.4”.

#### **Phase Change Material tools (Energain and BASF): Details**

- After applying changes to the TBD, error messages would appear although the operation was successful. The errors no longer appear.
- Due to a change in how the unit is displayed, the building element width might display the incorrect width with an older TBD file. To fix this, re-export the T3D file into the TBD file.

#### **90.1 Studio: Details**

- Fixes for pre-generation file checks when there is no proposed T3D file.
- Reports can now be generated whether or not project details have been entered.
- After a successful batch simulation, closing the message box also closes the batch simulation window.
- Selecting “Remove” on the root baseline folder removes all baseline files from the project.

#### **Systems Wizard (TPDx): Details**

- When reusing a TPDx2013 file, and a design day has been deleted from the TBD, display an error if any components are assigned to that design day. Previously this would cause a crash.
- Fix for unhandled error if a bad TSD file is selected.
- 90.1 Cooling Tower setpoint can now be edited in the Wizard.
- Heat pump “Duty:Fan Load Ratio” has been corrected to “Fan Load : Duty Ratio”.

#### **SAP Geometry Tool: Details**

- Export stops if a surface link error is encountered.
- Fix for a bug where building elements could be incorrectly added to the TBD if the text file referred to a building element not present in the TBD.
- Additional information added to some error messages.

- More informative error messages for unexpected surface data.
- Reclassified some impossible bridges as “unrecognised”.
- Impossible bridges in cold area dwellings are now ignored.
- Fix for missing construction data when name contains a comma.

#### **90.1 Airside Efficiency Tool: Details**

- The appearance of the data grid has been altered to assist copy and pasting.
- Exchanger panel cells now correctly coloured white or grey when the grid is first shown.

#### **90.1 Plant Efficiency Tool: Details**

- Served floor area is now shown on the table – the value is calculated during each sizing run.
- The appearance of the data grid has been altered to assist copy and pasting.
- Fix for the displayed efficiencies for heat pumps using the 90.1-2013 methodology. This was a display issue only and does not affect results.
- A check has been added to the Lua code to ensure that heat pumps are using the Single Split option.

#### **Design Day Wizard: Details**

- If a TWD which contained two weather files with the same name, the wizard would crash. Now the wizard will ask the user to rename one of the two weather files.
- Fix for a bug that would stop the reports from generating if a zone was setup on a HDD or CDD but had the output option unticked in TBD.
- Fix for an issue where if the Amend Temperature button was pressed twice in a row, the cooling design day would not simulate as the day number would be set to -1.

#### **Report Generator: Details**

- TM52 report code refactored, to allow for more flexibility with the new BB101 and TM59 reports. Should have no impact on results.
- TM59 report added.
- The Cooling Loads bookmark on the Peak Loads Report will now take you to the Cooling Loads sheet in excel, previously was moving to the bottom of the Heating Loads sheet.
- Fixed for a bug where if a zone was not a member of any zone groups the Peak Loads report would report the loads for the zone as zero.
- When reports are exported to Excel, the sheet names will now have a unique name rather than “Sheet 1” etc.

#### **PMV and PPD Tool: Details**

- Added columns for Average PPD and Floor Area to the Peaks table.

#### **Documentation: Details**

- Updates for Revit gbXML guide.
- Updates for SAP Geometry Tool guide.
- Updates for TPDx NPO guide.
- Updates for the CBDM guide.
- New guide for the TM59 Wizard.
- New guide for Tas General Optimisation.

#### **Constructions Database (TCD): Details**

- Condensation rate and vapour pressure graphs have been visually updated for all constructions.
- Grids on the construction and material pages have been updated.
- Updated the tabs.

**Calendar Database (TCR): Details**

- Updated the list box and selection buttons on the calendar page.

**Internal Conditions Database (TIC): Details**

- Updated the tabs.
- Updated the Graphs in the profile dialog box.
- Updated the grid on the schedule page.

**Weather Database (TWD): Details**

- Updated the tabs.
-

## Tas Version 9.4.1

### Evolution

- The TPD file type has evolved since 9.4.

### Building Simulator

- “Null Link” has been renamed to “Adiabatic” in all parts of the software.

### 3D Modeller

- gbXML import report now summarises the number of “reverse due to inconsistent angles” message rather than detailing for each gbXML surface.
- gbXML new import options:
  - When merging in a revised gbXML file, an option to use any new space names or to match the CADObjectID's of the imported gbXML spaces to assign zones. In the first case new zones may be created, with the new names.
  - Option to assign zones to selected spaces only. All other spaces will be imported but left unzoned.
- Initial 3D window is now anti-aliased. Also printed, saved images and videos are also anti-aliased.

### Systems (TPD)

- Component libraries saved in an earlier version of Tas could not be evolved up to 9.4 correctly, resulting in strange property values. Fixed. This would only affect users who had added custom components to their library. EDSL may be able to manually recover files with custom components which have already been incorrectly evolved up – contact Support.
- New component: Direct Evaporative Cooler. This is similar to the Spray Humidifier but uses a temperature setpoint rather than a humidity setpoint. It also features a water tank size property and a property allowing the tank to be purged if not used for a set period. See the Component Guide for more details.
- PV panels using the power temperature coefficient were giving incorrect results due to an error in calculating the panel temperature. This has been fixed.

### 3D Visualisation (Building Simulator and Results Viewer)

- Option to add timestamp to filename to ensure unique filename.

### UKBR Studio (2013)

- Criterion 3 blinds check now checks substitute elements. This also applies to the Criterion 3 report from the Report Generator.
- If a zone changed from an activity with display lighting to one without during a project lifespan, the lighting in the actual would have extremely low display lighting efficacy, with no way of manually remedying this. This would result in absurdly (and obviously) high lighting consumption. Now, in such cases, display lighting efficacy is reset to the notional default of 22.
- EPCs for Northern Ireland were incorrectly output with country set to England and Wales instead. Fixed.

### UKBR Studio (2010)

- Fixes for bugs in PV panel setup. The PV results are now consistent with current UKBR studio (2013) results.

## **IDF Wizard**

- EPW files can now be used as the weather source for an IDF import.

## **DOE Importer**

- Better resolution of internal conditions.
- Supports more inputs, including:
  - EQUIP-SENSIBLE and EQUIP-LATENT for SPACE.
  - OUTSIDE-EMISS for GLASS-TYPE.
- Supports .IN format.
- Able to resolve inconsistent roofs and floors in more situations.

## **Report Generator**

- Added a new Daylight report, which outputs the results of a daylight calculation from the t3d file.
- Added a new Window Group report, which will report properties of windows and window groups in your Tas models.
- With reports that allow for multiple files to be selected, the files can now be multi-selected from the open files dialog.
- On the File Selection page, a right click option has been added to remove a selected file.

## **Units**

- MBtu is ambiguous and recommended against. In Tas, it always represented 1000 Btu - it has now been replaced with kBtu (nonstandard, but unambiguous).

## **Design Day Wizard**

- Option added allowing the user to choose cooling design day weather based on peak global radiation.
- Right click option added to reported zones on HDD page, allowing for their settings to populate the input boxes.

## **PMV and PPD Tool**

- Added an option for the PMV Frequency results to be reported in intervals of 0.5 or 0.25.

## **90.1 Studio**

- When the Proposed building was using lighting functions, the Baseline lighting gain was sometimes set to zero. This has been fixed.

## **Climate Based Daylight Modelling (including Tray App)**

- Variable start and end hour.
- sDA metric variable percentage of target time.
- CBDM report fix for material reflectance/transmittance summary.
- Trouble-shooter added to the tray app.
- Performance improvements for wizard and tray app.
- Automatic image generation for CBDM report.
- Workers that come online after a calculation starts are no longer included by default.

## **Daylight Analysis Wizard**

- EFZ has variable target sky factor percentage.
- Permeant overshadowing has variable start hour, end hour and sample interval.

## Further Details

### Building Simulator (TBD): Details

- Aperture function dialog showed description incorrectly for RDWOM function – zone name and override zone group were reversed in one sentence. This was a display issue only. Fixed.
- Under some conditions the BRE daylight factors option would set an incorrect daylight factor of zero. This is now fixed.
- Clicking a database button or the 3D file button on the toolbar will now, if the path is not valid, immediately ask the user to select a path.
- ‘Calculate BRE daylight factors’ when a building element had no construction caused a crash. Fixed. For the purposes of the calculation, such surfaces are assumed to be opaque.

### 3D Modeller: Details

- The performance for picking in a 3D window has been improved, in particular for a high resolution screen.
- Running daylight calcs following a CBDM calc without recreating the analysis model (or reopening the file) caused very low lux values/factors to be displayed. Fixed.
- A small window pane area is now detected, such that just the frame is exported for analysis. This was preventing any simulation.
- The storey name is now optional in a gbXML file.
- An attempt to create an analysis model with only imported shades will now display an error message rather than crashing.
- Shadows are now displayed in video/set of images if current view has sun position as “too low”
- Prevent crash when displaying Tools menu with a 3D space selected in a gbXML generated floor plan.
- If a zone had tags but was not actually applied to a space, export would fail if creating zone groups for tags. Fixed.
- Adding a tag to (or clearing tags from) a zone group would seemingly add it to child zones, but when the user pressed OK, the tags would not be added to the zones. Fixed.
- Drawings can now be imported while a 3D view is active.
- “Default ceiling height” has been renamed to “Default storey height” – functionality remains unchanged.

### Results Viewer (TSD): Details

- Some columns (Occupancy sensible gain, Inf/Vent gain) would show power units when ‘Divide by area’ was enabled – this affected headers only, not values.

### Systems (TPD): Details

- Under some circumstances when results period was changed, the day and hour selected would change. Fixed.
- Lua modifiers can no longer be applied to zone components. These would not work in past versions and their inclusion in the software was accidental.
- Hourly results are now only stored for the main simulation period.
- The “Unlimited” sizing option can no longer be selected for Ice Storage Chiller duty and ice storage capacity, or for Dry Cooler fan flow rate. The “Unlimited” option for these properties served no purpose in earlier versions.
- Many components previously had properties referring to visual position (e.g. “Design Pressure Drop (Right)”) – this was relative to the schematic, and was only logical if the component had not been rotated. These properties are now numbered instead (e.g. “Design Pressure Drop (2)”). This now matches modifier names (e.g. Water Flow 2). When such a component is selected, number labels will appear on the schematic.

Affected components: Exchanger, desiccant wheel, tank, heat exchanger, water-to-water heat pump, water source chiller, water source ice storage, water source absorption chiller, water source direct absorption chiller)

- Heat rejection components have changed in size, and cooling towers have changed in appearance.
- Chilled beam heating load was missing from the result graphs. Fixed.

#### **Systems Wizard (TPDx): Details**

- Correction for the descriptions for the VRF systems.

#### **UKBR Studio (2013): Details**

- The 2010 to 2013 file upgrade asked for (and only accepted) v5.2.4 NCM internal conditions database, not the current one.

#### **3D Visualisation (TBD and TSD): Details**

- Tooltip now only shows if the visualisation control has input focus – prevents tooltip stealing focus from other controls/windows.

#### **SAP Geometry Tool: Details**

- All junctions between External Walls and Glazed Roofs are now treated as R3 Jamb bridges.

#### **IDF Wizard: Details**

- Exported IDF version updated to v8.6.

#### **DOE Importer: Details**

- More materials added to the library.
- Option to resolve inconsistent roofs and floors is now ticked by default.
- Fix for issue where additional heat transfer was sometimes not added to glazing.
- Fix for issue where surface plan perimeter was sometimes not calculated.

#### **Documentation: Details**

- Updates for TPDx NPO guide.
- Systems Component Guide updated.
- Design Day Wizard Guide updated.

#### **Passivent Tool: Details**

- An error message would appear after the tool finished running. Fixed.

#### **Energain Thermal Mass Builder: Details**

- Message boxes were appearing while changes were being applied to the TBD. Fixed.

#### **90.1 Studio: Details**

- Fix for an issue where the “Next” button would not always display on the first page of the Generate Baseline Buildings tool.
- If t3d filepath differed in case from when originally saved, would be reported as incorrect file. Fixed.
- A bug was introduced in 9.4 which prevented baseline creation for buildings featuring rooflights. This is now fixed.
- Fixed a bug which would prevented adjusting baseline lighting if the TBD contained empty zone groups.

#### **Report Generator: Details**

- The Control Method property of the DX Coil was not reported on the Air Side Systems Report. Fixed.

- The new Systems component, Direct Evaporative Cooler, added to the Air Side Systems Report.
- When the Systems Water Side Report was run on a System file with a pump not connected to a circuit the report would crash. Fixed.
- Systems Water Side Report properties have been updated to reflect the change of notation in Systems.
- If a corrupted file was selected or a file was moved after being selected, it would cause the Report Generator to crash on the options page. Fixed.
- Reports are now ordered alphabetically on the Select Report page.
- On machines that do not use '.' as the decimal separator, a band of zero could be entered into the frequency report. Fixed.
- All reports now use "," as the decimal separator on machines that do not use '.' as the decimal separator.

#### **Design Day Wizard: Details**

- Default values for Infiltration, Ventilation and Radiant Proportions were displayed incorrectly on the HDD setup page when the computer's numerical format did not use '.' as the decimal separator. Fixed.
- The two reports now use "," as the decimal separator on machines that do not use '.' as the decimal separator.
- If the pre-conditioning value entered into TBD was bigger than 50 days, the design day wizard would not finish. Fixed.
- If an Internal Condition's name was less than 6 characters long, it would not appear as an option in the CDD setup page. Fixed.

#### **PMV and PPD Tool: Details**

- Default values were displayed incorrectly when the computer's numerical format did not use '.' as the decimal separator. Fixed.
- If the tool was run repeatedly on the same file without closing the tool down, the xml file saving the settings would not be produced. Fixed.

#### **Weather Database (TWD): Details**

- Wind Rose period menu gave unpredictable behaviour. Fixed. Also applies to Building Simulator.

#### **IC Generation Tool: Details**

- Tool would not start if user had never changed settings in Tas Manager. Fixed.

#### **Phase Change Material tools (Energain and BASF): Details**

- Tool would not correctly assign constructions. Fixed.
-

## Tas Version 9.4 (post-release)

### Building Simulator

- Many list views were not working if a foreign language was enabled. Fixed.
- Ventilation functions (other than TCBVC) were not producing correct ventilation rates. Fixed.

### UKBR Studio (2013)

- If the Actual building had rooflights or roof windows that were Internal or Link surfaces, then the resulting TBD file would fail to simulate. Fixed.

### Report Generator

- Italian translations were outdated. Fixed.
- Direct Shading report failed if the TBD file had shading data calculated for 365 days. Fixed.
- In the TM52 report, peak temperature and daily weighted average would be reported incorrectly on the zone-by-zone breakdown if the computer's numerical format did not use '.' as the decimal separator. Fixed.

### Building Generators

- Building Generators for Part L 2006 and Section 6 2010 would incorrectly report building elements with unassigned constructions, stopping progress. Fixed.
- 

## Tas Version 9.4

### Evolution

The following file types have evolved since 9.3.3:

- .T3D
- .TBD
- .TSD
- .TPD
- .ukbr2013
- .TAI

### Tas Manager

- When selecting a file in Tas Manager, the right-click menu has a new option to reveal the Tas version in which that file was last saved.
- Weighting factor option removed from batch simulator. This option is now always used.
- Invalid keys now display 'Invalid Key' to their right, rather than a misleading number of days.

### 3D Modeller

- Two instances of T3D can now run at once.
- 3D surfaces can now be imported from DWG files for shading and daylighting calculations (see section below).
- New feature: Tags. Zones may now be assigned tags in the Zones dialog, or by selecting zoned spaces and using the right-click menu item 'Add Tag to Zone(s)...'. When exporting the 3D model to a TBD file, there is a new option: 'Create Zone Groups for Tags'. This will create a zone group for each tag you have used, and assign the relevant zones to it. Please note this process is additive only – zone groups for unused tags will

- not be destroyed, and zones will not be removed from any zone groups they were previously in.
- New option: 'Create Zone Sets for Floors', found on the Generate Building dialog. In addition to the standard zone sets, this will create a zone set for each floor of your 3D model, populating it with all the zones found (even partially) on that floor. Please note, if a zone is spread across multiple floors, it will be added to each of these zone sets.
  - Surface output specifications are not removed from surfaces during export from the 3D model.
  - Windows now have Internal Shadows turned on by default. Whenever a window or building element is set as transparent, Internal Shadows is turned on (though can be turned off again by the user). When a window or building element is set as opaque, Internal Shadows is always turned off.
  - New option: 'Choose Initial Colours...' found in the Building menu. This allows the user to select the colours used when creating default and new building elements, windows, shades and floors. Please note this will not affect existing elements, etc., only those created after this option has been changed.
  - Vertical offset of windows can be changed within a group. This allows, e.g. four identical windows to be placed one on top of the other using a single window type. Editing the level of a window type will not affect the vertical offset of that window type in existing window groups.
  - New right-click option with select wall: Set as Grid Angle: changes the grid angle to match the angle of the wall.
  - New right-click option with select wall: "Extend/Corner to", for intersecting the selected wall with another wall.
  - Option to select all walls associated with a selected space.
  - Having the "Analysis Colours" dialog open no longer prevents viewing or editing the model.
  - Opening the space properties dialog now selects the related zone in the zones list.
  - Analysis model is now saved to file and not recreated each time T3D file is opened.
  - Using the Set Zone tool and clicking on a zone has a new function while the CTRL key is held down. Instead of setting the zone in the selected space, the zone selection will be changed to match the zone which has been clicked on. The equivalent is also true of the other Set tools while CTRL is held down (e.g. CTRL + Set Window changes the window selection to match the one clicked on). Clicking on a space twice (or more) with CTRL held down in Set Zone mode will move the zone name text within the space.
  - Holding ALT while placing a window activates the "Fit to Wall" command on the new window.
  - Option to distribute shadow calculations amongst other computers on the same network, when exporting geometry to a TBD file. For more details, see utilities.

## Daylight

- New climate based daylight modelling (CBDM) wizard. For more details, see utilities.
- Daylight ranges dialog (used for setting the ranges used when displaying daylight results on the grid) now has a new checkbox: 'Interpolate mid values'. This will evenly distribute the range limits between the user-specified upper and lower bounds.
- Daylight Calculations: New button to select all zones for calculation. Warning displayed if zone status has changed, e.g. if a zone which previously had no access to daylight now has access.
- Floor area added to daylight calculation results dialog.
- New Vertical Sky Component option on the accuracy drop-down menu.
- Menu options for the results display are now shown in a dialog.
- When attempting to begin a daylight calculation without an analysis model, user will be given the option to create an analysis model.
- Daylight results dialog now has a button to display the current results on the active floor plan.

### **gbXML Import**

- Internal walls and null walls can now be added in the 2D plan view of an imported gbXML floor. This can be used to subdivide areas, e.g., to separate core and perimeter zones.
- The 2D Floors import option has been removed.
- In the “Import gbXML File” dialog there is now an option to toggle grey inner surfaces on and off.
- Button on “Import gbXML File” dialog to display “Analysis Colours” dialog.
- When viewing the errors and warnings for an imported gbXML model, different colours are used to highlight the floor of the zone and the surface which has the issue.

### **3D DWG Surface Import**

- A 3D view of the DWG file is displayed as well as the 2D view when the file is opened. Note the points to set the scale and mapping can only be selected on the 2D view. Most of the 3D view manipulation works i.e. shaded/wireline, perspective/isometric, isometric views top, left etc., pan, zoom and orbit.
- If the scale is not set by selecting 2 points, then a “default” scale is set from the units in the DWG file. When the 2 points are selected a distance is displayed in the distance edit box indicating what the distance would be if the default units are used (Good for checking)
- There is a new option to Import as Shading Surfaces. When selected this will get all the 3D polygons (triangles) from the currently selected layers. The z position of the DWG data that is mapped to a zero z position in the TAs model is required. When the 1st scale point is selected the z value of that point is entered into this edit box as a guide to what this should be.
- When the dialog is OK'd, the 3D polygons are created as shading surfaces within the 3D Tas model (they are the same as gbXML shade surfaces). If such surfaces already exist then the user can either add to them or replace them. Note that at the moment it is not possible to combine a gbXML model with imported shade surfaces from a DWG file.
- These 3D polygons are grouped into a storey – “Imported Drawing shading surfaces”. This floor can be deleted to remove all surfaces. Individual surfaces can be selected from the 3D view and have the same options as a gbXML shade surface.
- Note that these 3D polygons are not displayed in a 2D plan view – it is still necessary to indicate that the drawing should be shown. It may be preferred to select the layers to create the 3D shade surfaces and then select a different set of layers for display in a plan view.
- These shade surfaces are included in the analysis model for both TBD shading and daylight calculations

### **Terminology Changes**

- Where “Floor” refers to a level of the building, it has been renamed “Storey”. This is to distinguish it from the other meaning of “Floor”, i.e., the surface at the bottom of a room or zone.
- Where “Width” refers to the breadth of a building element, it has been renamed “Thickness”. This is to avoid confusion with other meanings of “Width”.
- “Default Wall Height” is now referred to as “Default Ceiling Height”.

### **Building Simulator (TBD)**

- New list views for Zones, Zone Groups, Building Elements, Aperture Types, Surface Output Specs, Feature Shades, Substitute Elements, IZAMs, Constructions, Internal Conditions, Design Days, and Schedules.
- The limitation on number of zone groups able to be simulated has risen from 300 to 8192.
- IC Generation Tool, Lighting Control Tool, Passivent Tool, Energain Thermal Mass Builder, and BASF Micronal PCM Utility now open from the Tools menu of TBD.
- BRE Daylight factors can now be calculated from the Tools menu of TBD.

- New Design Day Wizard (see below).
- New SAP geometry tool (see below).
- Right-click options in building element to remove construction, substitute elements, apertures, and feature shades.
- Different icon for null building elements.
- Error messages now use zone names rather than zone numbers.
- General Details pane has been reorganised slightly. Building Name and Total Zone Floor Area are now visible here.
- If there are any messages in the presimulation checks dialog then when the user presses simulate a message box will be displayed, giving the user the option to continue the simulation or view the presimulation checks dialog. This check is optional and can be turned off in Tools->Options->Preferences.
- Convection coefficient and daylight factor can be applied by zone group.
- Output Groups are now obsolete and have been removed. Output groups in older TBD files will be converted into normal zone groups during file evolution.
- HVAC group maximum heating and cooling values can now be entered per unit floor area.
- The Aperture Function dialog has been reworked. This dialog now allows the user to access the new ZDCCM function, which works much like ZDCM but including 'smart' external temperature cut-off. The user can now also choose, for many functions, whether to include the zone temperature cut-off - if it is disabled (using the 'Mixed Mode Cut-off checkbox) for a function that uses it, the cut-off will be set to 150°C, essentially disabling it.
- Latitude/longitude mismatch is now triggered if the time zone differs by more than 0.25hr from that used when shading data was calculated (Time zone is, after all, essentially longitude correction).
- Tas v9.3.3 (and v9.3.3b) used the shading sun position (i.e. that used during shading calculations during 3D model export) for solar gain calculations. As of v9.4, Tas once again uses the actual sun position for each day, now with an added check to ensure the correct side of a surface is receiving sunlight.
- The TCBVC ventilation function has been altered. During the daytime, if the external temperature is below a user-specified cut-off, flow will be determined by pollutant level rather than temperature. Existing function definitions without the extra parameters will be unaffected.
- If the TCBVC ventilation function was used for a zone on one or more daytypes, then the ventilation rate would be set to maximum flow for that zone on daytypes where the function was *not* used. Fixed.
- If TCBVC was used, and the override hours were both in the morning, then the ventilation between midnight and the last hour override would be incorrectly treated as being between the override hours. Fixed.

#### **New Design Day Wizard**

- Launches from TBD Tools menu.
- Takes inputs from the user to create heating and cooling design days.
- Simulates the design days to produce a reports detailing sized heating and cooling loads.

#### **New SAP Geometry Tool**

- Launches from TBD Tools menu (see new documentation in user guides folder).
- Geometry analysed in accordance with SAP 2012 guidelines and output to an Excel workbook.
- Multiple dwellings can be assigned from a single TBD, each has a separate page in the Excel document.
- Floor area and volume on a storey by storey basis.
- Areas, thermal loss, and thermal mass for each surface type.

- Thermal bridges measured, identified, and listed.
- Comprehensive details for each window and door in the dwelling.
- Optional export of NHER Plan Assessor v6 XML for each dwelling.

### Result Viewer (TSD)

- Output Views now allow the user to select a zone from within the current Output Selection, filtering the results displayed.
- Tickboxes in output view and in export to excel to allow gains and loads to be viewed per floor area. In order to take advantage of this new feature, the TBD must be simulated in the latest version.
- Zones and zone groups have a new button to view a performance summary for this zone or zone group. These performance summaries can also be viewed via a right-click option in the tree view. Please note that with large TSD files there may be a short delay in creating these summaries.
- Performance summary now also shows maximum loads per floor area. In order to take advantage of this new feature, the TBD must be simulated in the latest version, otherwise zero will be displayed for all per area results.
- Option to include zone volumes and floor areas in export to Excel. In order to take advantage of this new feature, the TBD must be simulated in the latest version.
- Browser buttons added (allowing navigation to recently viewed items, as in TBD).

### 3D Visualisation (in both TBD and TSD)

The 3D Visualisation has undergone a significant number of changes – the appropriate manual details the full behaviour.

- The right-click menus have been re-organised, and some commands have changed name to more accurately reflect their behaviour:
  - 'White Background' and 'Black Background' are now found within the 'Draw Options' sub-menu.
  - 'Black Outlines' and 'White Outlines' are now found within the 'Draw Options' sub-menu.
  - 'Draw Outlines' is now found within the 'Draw Options' sub-menu.
  - 'Enable Transparency' is now found within the 'Draw Options' sub-menu.
  - 'Fill Unfocussed Surfaces' and 'Outline Unfocussed Surfaces' are now found within the 'Focus Options' sub-menu.
  - 'Show Compass Rose' is now found on the Display Options dialog.
- 'Grey Inner Surfaces' (Building Simulator) has been replaced with 'Chequer Inner Surfaces'. The behaviour is the same, but surfaces are drawn with a chequered pattern of their original colour, making it easier to see their original colour, and being distinguishable on grey surfaces.
- The 'polar scale' (blue -> dark grey -> red) now uses different colours. The lower (negative) half uses a blue -> cyan scale, the upper (positive) half uses a red -> yellow scale, and the zero values are displayed in purple. This should make the image significantly easier to read, and distinguishes between values much more clearly.
- Insolation display no longer takes into account construction absorptance. Insolation is intended to be the amount of sunlight falling on a surface, not absorbed by it.
- 'Show shading sun position' option (Result Viewer) has been removed. The sun position displayed is the one used for the solar calculations, which is always the current day.
- Analemmas are now positioned at the half-hour mark, matching the time Tas uses for solar calculations.
- New option: 'Export...': Accessible from the right-click menu, this allows you to export a PNG image file, an AVI movie file, or a series of PNG image files. This new functionality is defined in full detail in the manuals.

- New feature: Pinned labels. Using the right-click menu command 'Pin label here', you can attach a label to a point on the visualisation of the model. The information displayed in the label can be defined in the Display Options Dialog.
- New feature: Focus. Optionally, the view can centre on focussed areas of the model, rather than always centre on the entire model. Options can be found in 'Focus Options' on the right-click menu.
- In the Results Viewer, double-clicking a zone now focusses the view on that zone. Double-clicking outside the zone or selecting a new output selection will reset the focus to the entire output selection.
- The visualisation in the Result Viewer now uses a calendar control, allowing more intuitive day selection. Please note, the year shown on the camera control is merely representative of the calendar start day, and is not relevant to the simulation.
- The visualisation now uses multi-sampling if permitted by your computer. This should produce much cleaner images. This can be disabled in the Display Options dialog, but the visualisation will need to be closed and re-opened for the setting to take effect.
- Scale legend labels would sometimes, unpredictably, be displayed at the wrong location, making the legend difficult or impossible to read. This issue is now fixed.
- Many computers, even with up-to-date drivers and good graphics cards, would display the 3D visualisation as though chopped up into many triangles, with distinct lines or gaps between them. The scale legend appeared semi-transparent, rendering it difficult to read. Fixed.
- Pressing the Enter or Escape keyboard keys while the Display Options dialog had focus caused that dialog to disappear, with no way to make it reappear until the 3D visualisation was closed and reopened. This issue is now fixed.
- The visualisation would treat the Alt key as a toggle rather than a held key. This issue is now fixed.

### **Databases (TCD, TCR, TIC, TWD)**

- Browser buttons added (allowing navigation to recently viewed items, as in TBD).

### **Systems (TPD)**

- Ashrae Fan Power Tool is now the 90.1 Airside Efficiency Tool, which can set efficiencies for fans and for exchangers.
- New 90.1 Plant Efficiency Tool for setting efficiencies for boilers, chillers, and air source heat pumps.
- New properties for Spray Humidifier to allow it to act as a Direct Evaporative Cooler.
- New properties for PV panel (these are not used in UKBR studio projects): Minimum irradiance, Nominal Operating Cell Temperature, Power Temperature Coefficient.
- Dry Cooler sizing overhauled, now uses design drybulb temperature and design range.
- New Dry Cooler fan properties to allow for different fan modes - minimum flow rate and variable speed fans option.
- Tooltips for component properties.
- Added Daily distribution type for Domestic Hot Water groups.
- "Optimiser" renamed "Air-Side Economiser".
- Additional results series for spray humidifier: Cooling and electrical load.
- New option in the View menu to reset workspace layout.
- The Cont controller has been renamed the Sig controller.
- Scroll bar sizes and positions are now based on the visibility of components placed on the schematic.

### **Systems Wizard (TPDx)**

- New DHW-only systems: Boiler with Tank, Boiler with SHW panel and Tank, and Boiler with SHW Panel and Two Tanks. These systems behave the same as creating a heating and DHW Boiler with Tank, etc., but can be created on the DHW panel. Heating

components cannot be added to these systems. These systems are also available in the UKBR Studio.

- Added Select All (Ctrl+A).
- Added sorting functionality.
- It is now possible to change DHW system type from the right-click menu, as with heating system type. Note that the DHW system type cannot be changed if a system is selected which includes a heating circuit.
- New layout for the Fancoils with Grouped Mechanical Ventilation system. The new setup uses fancoil zone components. The change means that this system now uses less computer memory, allowing larger systems to be simulated. This system is not used for UKBR Studio projects. Simulation results for the new and former setups will be different.

### **Ambiens (TAI)**

- Starting RH is now retained when the file is saved and reopened.

### **UKBR Studio (2013)**

- Can now have more than one lighting design in a single file. Only one design may be active at one time. There is a new page in the studio where the user can switch between lighting designs.
- If building element types were defined in the 3D model, then this will be used to identify the building element type when the TBD is loaded into the studio. In all other cases the type will be guessed from the element name, as before. In order to take advantage of this new feature, the 3D model must be exported in the latest version.
- Added sorting functionality.
- A very rare error during file saving caused the tlp2013 file to be rendered unopenable, giving the message "Object reference not set to an instance of an object". This is now fixed. Files already affected by this problem can be fixed by EDSL support.
- District Heating CO<sub>2</sub> factor would be reset to the default value whenever the file was opened, even when the user had defined a different value. This is now fixed.
- A design illuminance column has been added to the lighting control table of the input summary.
- Non-exposed surfaces with a building element that was set to Roof would cause an infinite loop during the Generate Notional Building step. This has been fixed. Please note; you should still take care that building element types set in the studio correspond to their usage in the model.
- Calculation method updated to include changes outlined in the NCM Modelling Guide (England) November 2015 and NCM Modelling Guide (Wales) June 2016. For details on the specific changes please consult the "UK Building Regulations 2013 Studio" manual.

### **Terminology Changes**

- Boilers are now referred to as "Heating Sources".
- Chillers are now referred to as "Cooling Sources".
- DHW is now referred to as "HWS".

### **Report Generator**

- Improved the formatting of the reports in Excel.
- Percentile Loads report added to the report generator.
- User's inputs are saved to an XML file for all reports. When the user works through the report for a second time with the same file, the saved user inputs will be read back into the report generator. To help re-populate the saved data, users now cannot have two schedules with the same name in the frequency report.
- Added a zone filter to the report generator tree views. Restricted the tree views so the tree nodes cannot be renamed.

- The air side systems report now reports the properties of each component, along with certain annual results.
- The plant room systems report now reports the properties of each component, along with certain annual results.
- Annual Loads Comparison report now compares results in zones common to multiple files.
- All reports (except the Peak Zone Loads report) now display a progress bar.
- Reports are now translated.

#### **Adaptive Overheating Report**

- Weather data can be reported in tabular format.
- User can now select any weather file.
- Building category can be selected.
- Option to report using PSBP criteria rather than TM52.
- Day by day breakdown for each zone.

#### **Annual Loads Report**

- Added monthly, weekly and daily outputs.
- Added a zone by zone breakdown.
- Option to report the loads per m<sup>2</sup> – in order to use this feature the TBD must be simulated in the latest version.

#### **Frequency Report**

- If an invalid start or end day is entered it now reverts to the TSD start or end day instead of day 1 and 365. If the end day is before the start day, swap them, if one of the days then falls outside of the TSD simulated period revert back to TSD start and end day.
- Improved output when using frequency aggregation option. Now supports more than 15 parameters. Improved clarity of column headers.
- Pollutant Levels now available as a parameter for use in this report.
- Up to 50 parameters now possible (Excel output only).

#### **Peak Loads Report**

- Options to report just heating or just cooling loads.
- Zones now ordered by zone number.

#### **Direct Solar Shading Report**

- This report can now be produced for only certain zones, rather than for all assigned zones in the 3d modeller file.
- This report no longer reports the zone number. Instead the orientation of the window is reported.

#### **Utilities**

- New PMV & PPD Tool (shortcut in Utilities folder) replaces the Thermal Comfort Prediction Macro.
- New BCA Section J2 Glazing Tool (shortcut in Utilities folder) to test glazing designs against the J2 Regulations (2015/2016).
- New Daylight Analysis Wizard which can be used for right of light calculations (Equivalent First Zone), Daylight Distribution, Vertical Sky Component, Permanent Overshadowing, Average Daylight Factor etc.
- IC Generation Tool, Lighting Control Tool, Daylight Factor Calculator, Passivent Tool, Energain Thermal Mass Builder, and BASF Micronal PCM Utility have been removed from the utilities folder. These utilities now run from within the Tools menu of TBD.
- Design Day Tool has been removed and replaced by the new Design Day Wizard (see TBD section).

- NHER Plan Assessor XML Export has been removed and replaced by the new SAP geometry tool (see TBD section).
- 90.1 Studio has a new option in the Tools menu to copy fresh air rate values from the proposed TPD to the baseline TPDs or vice versa.
- Solar Gain Check Part L has been removed. Use the Part L Criterion 3 Solar Gain Check instead.
- New worker peer tray app, for use with the climate based daylight modelling wizard (**CBDM**) and distributed shading calculations. When running, this application can be used to perform calculations from other computers.

#### **IC Generation Tool**

- Import and save hourly profiles.
- Option to load hourly profiles specific to BCA Section J 2015/2016.
- Option to create new multi-zone conditions instead of one IC per zone.
- Option to set gain view coefficients to zero.
- Option to create schedules for simple profiles rather than write hourly profiles to the TBD.
- Option to delete all unused profiles from the profile editing dialog.
- Schedules are now imported (as hourly gain profiles).
- Hourly gain and thermostat profiles can now be imported from existing internal conditions.

#### **Macros**

- The Thermal Comfort Prediction macro has been removed and replaced by the new PMV & PPD Tool.
- The Annual Loads, Zone Loads, Peak Zone Loads, Frequency, Summaries and Checks, and Wind Rose macros have been removed.

## Further details

### 3D Modeller: Details

- During export to TBD, Null building elements are now forced to have no construction.
- The "Display Windows" option has been renamed "Display Windows and Shades" which more accurately represents its function.
- Warning message relating to internal shading now only appears when window is transparent.
- Building element type is now set for windows and shades exported to TBD.
- Existing backup files (.bak) no longer prevent file evolution.
- Fix for an issue where selected items remained selected when switching between views.
- When copying walls and windows between storeys they will now ignore grid snap.
- Warning for a zero thickness element now names the element.
- Zones dialog minimum size increased to stop buttons hiding each other.
- The Import Drawing dialog can now be resized horizontally to view longer layer names.

### TBD: Details

- Summary output now has darker text for better visibility when opening in Excel.
- Summary output for zones now includes a list of the assigned internal conditions.
- Zone groups can now be dragged from zone group list views onto the tree view to copy all zones from one zone group into another. It is now also possible to copy all the zones from a zone set into a zone group by dragging the zone set from the tree view into a zone group view (it was previously possible to drag zone groups in this way but not zone sets).
- New presimulation check for internal condition with lighting control applied to zone with a daylight factor of zero.
- New presimulation checks for zones with fewer than four surfaces, where a single surface accounts for >49.5% of the total zone surface area, or where all surfaces are Null.
- New presimulation checks for wind speed > 50m/s and diffuse radiation > global radiation.
- Presimulation checks for bad combinations of solar in MRT and view coefficients have been removed.
- Weighting factor option hidden from simulation dialog.
- Cancelling simulation now asks for user confirmation.
- The simulation error message for zone air flow imbalance now states the figures for flow in and out of the zone.
- Area and building element type have been added to the building element view.
- Zones in the tree view now have tick icons to indicate whether an internal condition has been applied.
- The aperture function dialog no longer cuts off very long descriptions.
- Zone Group Types list view now shows zone groups with no zones as "-" in the Output field. Previously it displayed "No".
- Pre-simulation checks for BB101 now correctly informs the user to use the Standard calendar.
- Using the browser buttons to navigate to an item that has since been deleted no longer causes an error. Instead, the command is ignored and item is removed from the history.
- Simulation error messages referring to the long-outdated term "zone divides" now correctly refer to "nulls" instead.
- In the Pre-simulation Checks dialog, selecting an entry referring to a since-deleted item (e.g. a construction) caused an error. Fixed.

### 3D Visualisation (in both TBD and TSD): Details

- The North angle displayed in the visualisation is, in models exported prior to Tas 9.4, back-calculated from surface data, which could sometimes result in an incorrect angle

being used. This is a display issue only. In models exported in Tas 9.4 and onwards, the north angle is included in the file, and so should match exactly between the 3D model and the 3D visualisations.

- Flow arrows now use softer colours (TSD only).
- Zooming was previously relative to building units, making it awkward to use with large or small buildings. Zoom speed is now linked to model scale, which should make it appear consistent.
- Some mice (including many ubiquitous Microsoft mice) were not able to zoom correctly using the scroll wheel. This issue is now fixed.

#### **Constructions Database (TCD): Details**

- "Include subdirectories" tickbox for searches now checked by default.
- It is now impossible to drag an opaque material layer to a transparent construction, or vice versa.

#### **Internal Conditions Database (TIC): Details**

- It is now impossible to apply functions to a profile in TIC – this can only be done in TBD.

#### **Systems (TPD): Details**

- Added an error for pumps with unknown design flow rates.
- Added an error for Load Sensors on Pipes.
- Added a warning for unused sensor arcs.
- Removed unneeded results series from Load Component.
- Rearranged the component library.
- Fix for DHW group design flow rate bug – now only uses the value shown.
- Fix for bug where dry coolers could sometimes have insufficient precooling water despite the water flow being set to "unlimited".
- Display an error when using PV panels or SHW panels and no TSD data is loaded.
- Correction for when cooling tower design water flow rate error appears.
- Fix for a display bug where the cooling tower could show an incorrect water flow rate value after sizing.
- Corrections for unit types for a few component properties and results.
- Display an error if function schedules are applied to the ice schedules of the Ice Storage Chiller.
- Steam collections are never used and are no longer added to new systems files.
- System served area now displayed as a property of airside systems (TBD must have been simulated in v9.4).
- Disabled manual addition of Lua modifiers to profiles.
- Some dimensionless properties are no longer labelled as "0-1", to avoid giving the impression that they should be limited to a maximum value of 1.
- The gridlines in schematics are now drawn to fill the view regardless of which part of the schematic is displayed.
- The Sig (previously Cont) controller schematic symbol is now a sine wave.
- The Lua controller schematic symbol is now a Lua logo.
- The Not controller schematic symbol is now a Not (¬) sign.

#### **Systems Wizard (TPDx): Details**

- For baseline VAV systems the wizard no longer sets reheat box minimum flow rates as this could cause simulation errors in some cases. The user must now check manually against section G3.1.3.13.
- Fix for situation where unwanted 90.1 baseline circuits would appear when importing an existing .tpdx file.
- Fix for airside system creation failure with VRF systems using non-sized cooling.

- Removed the check for the TPD file when reusing a tpx2013 file. The initial filepath for the new TPD will now be in the current folder rather than always suggesting overwriting the existing TPD.
- The option to modify the existing project must now create a new plantroom rather than edit an existing one.
- The Next button has been greyed out on the last panel of the wizard, where it has no function.
- Fix for a rare issue where the boiler dialog would appear when heating system type was changed.
- “Fresh Air Fan” has been renamed “Supply Fan” in all cases.
- New Natural Ventilation and Occupied and Unheated Systems will have all the zones contained within a single group.
- Fix for an issue which prevented Fancoil systems from being created without a heating circuit.
- Staged chiller setup was mislabelled, now corrected.
- CHP efficiency now named “Overall CHP Efficiency”.
- When adding a new zone to an existing Extract Only system, the new zone will use the same settings as the rest of the system rather than adopt default values.

#### **90.1 Airside Efficiency Tool: Details**

- Regulations version must now be specified when entering a custom fan efficiency.
- Fix for display if user has changed the Windows text size.

#### **UKBR Studio (2013): Details**

- More informative error for trying to overwrite a folder that doesn't exist.
- Buttons on lighting control page to expand and collapse folders.
- Confirmation yes/no message box when overwriting certifier details.
- Light wattages were being reported incorrectly on the BRUKL document when lighting was specified by efficiency – they were multiplied by the zone illuminance. This was a display issue only and did not affect other calculations. This has been fixed.
- Attempting to launch the studio with restricted access to the registry could cause the studio to fail to open, displaying an unhandled exception dialog with the message “Access to the registry key ‘HKEY\_LOCAL\_MACHINE\Software\EDSL\TasManager’ is denied”. This has been fixed.
- The labels for Building Type and Building Stage were swapped on the General Details tab. This has been fixed.
- Side-lit metal-clad spaces were not receiving the correct amount of glazing in the notional geometry. This only occurs for a number of Industrial and Warehouse internal conditions. This has been fixed.
- Improved display for BRUKL/EPC input fields if user has changed the Windows text size.
- New warning for missing shading data in source TBD.
- Fix for a file encoding issue which under some circumstances could create incorrect characters in a BRUKL or EPC.
- Tank storage losses, as displayed on the BRUKL document, are now calculated using the volume of the tank. Previously they were calculated using the volume of water processed. This was a display issue only.
- Lighting Efficiency on the Studio Input Summary report is now reported to 2 decimal places.

#### **UKBR Studio (2010): Details**

- Fix for a file encoding issue which under some circumstances could create incorrect characters in a BRUKL or EPC.

### **Report Generator: Details**

- Corrected an issue on the Annual Loads report where the LOE column was being incorrectly calculated when the multiplicity for a zone was bigger than one.
- Corrected an issue with the Frequency report where additional empty columns appeared when running the report in landscape mode.
- Corrected an issue using RH in the frequency report where the limits were named Start Temperature and End Temperature.
- Frequency report when using the frequency aggregation now reports correctly when the difference between the start and end variables is bigger than or equal to 20 (no matter the unit).
- Fix for units displayed for Frequency report using US units.
- The Frequency report no longer accepts a band of zero.
- When the user's inputs mean that a frequency report would require over 20 parameters, the user will be warned before trying to produce the report.
- Corrected an issue that caused the error messages to appear with no text when setting up a Peak Loads report.
- If a zone appears in more than one TSD file when trying to produce a Peak Loads report, a warning will appear telling the user to use the Peak Loads Comparison report.
- When the frequency report options were validated, an unsuccessful validation resulted in the temperature limits being set to the start and end day text boxes. Fixed.
- TM52 report generation sped up for large models.
- The Frequency report now takes the external weather data from the TSD file, rather than the TBD file.
- Added a warning to the Adaptive Overheating report to notify the user that the weather data is being taken from the TBD file.
- The same TSD file can no longer be selected more than once for the Annual Loads Comparison report.
- The Cost Comparison report now displays the month labels correctly and displays results for all twelve months.

### **Documentation: Details**

- Updates for Revit gbXML guide and TPDx NPO guide.
- New guides for modelling Breathing Buildings units in Tas.
- New guide for carrying out Climate Based Daylight Modelling in Tas.
- New guide for using the new SAP geometry tool.
- New guide for the Design Day Wizard.
- New guide for the Daylight Analysis Wizard.

### **90.1 Studio: Details**

- Additional checks to ensure that files have not been moved or deleted.
- Fix for display if user has changed the Windows text size.

### **IDF Wizard: Details**

- Option during import to calculate daylight factors according to BRE methodology.
- Fix for IDF export when item names in TBD contain exclamation marks.
- IDF export uses TBD north angle if available (For TBDs created in v9.4 and later), rather than calculating this from the room geometry.
- Changes to allow imported IDF files to work with TBD utilities.
- Support for more date formats.
- Support for computer locales using comma as a decimal place.
- Support for more coordinate system formats.
- Fix for bug where two TBD building elements could be created with identical names.

- If the occupancy gain sensible proportion is defined as “autocalculate” in the IDF file, the utility will now calculate it based on the metabolic rate. Previously the sensible fraction would default to 1.
- When exporting IDF, frame divider type is now set to the default.
- When exporting IDF, window gas type is now set to the default.
- When exporting IDF, Simulation Control and Run Period objects are now created.
- When exporting IDF, glass walls are now represented as a window hosted within a dummy surface.
- Exported IDF version updated to v8.5.
- Fix for file encoding issue which might have caused bad data in exported IDF under some circumstances.
- Fix for a bug in IDF export which could locate a window within the wrong surface.

#### **DOE Importer: Details**

- Option during import to calculate daylight factors according to BRE methodology.
- Changes to allow imported INP files to work with TBD utilities.
- Fix for window altitudes on storeys using multipliers.
- Support for computer locales using comma as a decimal place.
- Fix for rare floor geometry bug.
- Additional support for older file formats.
- Fix for a bug in internal condition creation which could prevent TBD simulation.

#### **IC Generation Tool: Details**

- When using the new multi-zone IC option and importing ICs with NCM lighting functions, a wall to floor ratio of 1 is assumed when calculating an equivalent efficiency.
- If the user pastes an invalid profile name into the grid, they will be given the option to import profiles and continue pasting.
- Support for US units.
- New column for lighting gain, applied to the internal condition in addition to any per-area lighting gain.
- Fix for loading lighting data from internal conditions using lighting functions.
- Ventilation is now included in the import from existing internal conditions.

#### **Lighting Control Tool: Details**

- Support for US units.

#### **Ambiens (TAI): Details**

- Fix for bug which meant some data could be missing from CSV output.
  - Fix for bug which could cause CSV output to crash.
-

## **Tas Version 9.3.3b (post-release, up to B.9058)**

### **UKBR Studio 2013**

- The INP file was being produced incorrectly for Scottish EPC projects, which would result in the EPC documents not being generated. This has been fixed.
  - The Scottish notional CO2 results did not take into account displaced electricity from PV panels. This has been fixed.
  - Potential CO2 emissions rate and England EPC rating inputs were added, without which Scottish EPCs could not be lodged.
  - Total annual delivered energy consumption was not taking CHP displaced electricity into account. This has been fixed.
- 

## **Tas Version 9.3.3b**

### **3D Modeller**

- Fixed an issue which meant that for some room shapes, grid points could be duplicated during daylight calculations, skewing results.
- Volumes and floor areas now recalculated in analysis model.

### **UKBR Studio (2013)**

- Scottish building regulations - Section 6 added to UKBR Studio.

### **UKBR Studio (2010)**

- Fixed an issue which meant some reports (Input summary, system summary, CO<sub>2</sub> emissions) could not be displayed.
- 

## **Tas Version 9.3.3 (post-release, up to B.8176)**

### **3D Modeller**

- Fixed an issue which meant that for some users 3D Modeller would not open successfully if a T3D file was double-clicked, or through automation (such as running from the UKBR Studio). Fixed.
- Fixed an issue which meant that editing the details (for example, the name) of a gbXML imported floor could sometimes cause the T3D file to become corrupted.

### **UKBR Studio (2013)**

- Fixed an issue which meant that some TPLP2013 files would fail to open, giving a message "Error Serialising from File".
-

## Tas Version 9.3.3

### General

- Building Simulator, Results Viewer and the database applications no longer lock files when they are open, allowing them to be open in more than one place at once (e.g. the Results Viewer can now show the 3D Visualisation while the TBD file is still open).
  - Note that a file cannot be saved while it is open in another program.

### Tas Manager

- Register dialog now has a 'Copy ID to clipboard' button, and a link to the key generation webpage (only available when the dongle is plugged in and recognised).
- On closing Tas Manager, network licence users will be given the option of revoking their seats.

### Building Simulator

- Memory allocation for simulation substantially overhauled, allowing buildings to have high numbers of zones or surfaces without causing a simulation error.
  - It is still a good idea to review a model with very high numbers of surfaces in a zone – this could indicate a poor zoning strategy.
- Additional presimulation checks for bad profile functions and for zones split between separate areas of the building
- New ventilation function, TCBVC, for separate day- and night-time modes of operation.
- There was, for v9.3.2 only, a problem with using wind pressure coefficient files. This has now been corrected.

### Systems

- Changed Plantroom Design pressure drops so that the capacity can also be None, removing their effect on the flow calculation.
- Valves have been rejigged to include the option of a Design Pressure Drop.
- Added a "Fresh Air Mixing Box" component.
  - Acts as an optimiser with no controls, so always trying to meet min fresh air.
- Ashrae Fan Power Tool changes
  - Support for 90.1 2013 methodology
  - Ability to set all systems to the same horsepower or efficiency method
- Partial free cooling now possible for water source chiller as well as on/off behaviour.
- New setpoint position options for water side heat exchanger.
- Water side heat exchanger controller signal behaviour changed to be consistent with air side exchanger.
- Cooling tower sizing and properties overhauled.
- Cooling towers can now use controllers.
- Profiles on PV and Solar Panel orientation and inclination to allow changes in panel position during the simulation.
- Added "Adjust setpoint for Optimiser" to exchangers.
  - This attempts to adjust the setpoint of the exchanger so that the temperature after the optimiser is correct for the setpoint.
- Added types to electrical groups allowing them to be categorised correctly in results.
- Simulation options are now more persistent.

### Systems Wizard

- 90.1 baseline systems 11, 12, & 13 now available
- Heating only option on airside exchangers
- Options in VAV, FATVAV, and PFPVAV for supply pressure reset and supply temperature reset

### **UKBR Studio (2013)**

- Lighting wattage was previously reported incorrectly on the BRUKL document for zones with specified lamp types.
- Gross internal area no longer includes unoccupied spaces.
- Scotland (pre-release) Section 6 implementation. Currently produces the BRUKL.exe input file and shows this to the user. The input file states the BER and TER for the Section 6 regulations that come into force on the 1<sup>st</sup> October 2015.

### **IC Generator Tool**

- hourly profiles for all gains, thermostat, and humidistat
- option to import existing internal condition data from TBD
- pollutant can now be included in created ICs
- option to set Solar in MRT for internal conditions
- radiant proportion and view coefficient for heating and cooling emitters
- option to replace existing IC assignments
- CSV output

### **Lighting Control Tool**

- New Lighting Control Tool for editing lighting controls within a TBD's internal conditions. This replaces the Lighting Control Macro.

### **IDF Wizard**

- The IDF Importer is now the IDF Wizard
- IDF Wizard can now export IDF files from a TBD file
- Support for wider range of inputs for IDF Wizard

### **DOE Importer**

- DOE Importer can attempt to correct badly defined roof and floor geometry

### **Ambiens**

- Measure mode added.
- Results can now be displayed over a background bitmap. User can set the opacity of the results layer.
- Results can be exported to a CSV file.

### **Ashrae 90.1 Studio**

- It is no longer necessary to rerun the Ashrae fan power wizard when air flow rates change.

### **Cymap Systems Tool**

- A new tool for transferring Systems results before importing your model into Cymap.
-

## Tas Version 9.3.2

- Italian language option now included for the first time! This can be in the Language tab of the Tas Manager Settings dialog.

### 3D Modeller

#### General

- Added "transparent Fill" option for "Show 2D Zones" to enable an imported DWG to be visible also.
- Windows dialog now has a 'Mirror' button. Creates a copy of the selected window group(s), but with the offsets of each entry altered such that the group is a left-to-right 'mirror image' of the original group.

#### gbXML Import

- When merging a revised gbXML file from Revit, existing surfaces are now matched using the CADObjectID in the gbXML file and the geometry of the surface rather than the surface names which are not unique.
- Ensures that floor/ceiling surfaces are always oriented the same way for the Building Element i.e. "inner" for the ceiling side and "outer" for the floor side. .
- New Tools menu option to "Reverse Incorrect Orientation Surfaces" that attempts to correct spaces with the "incorrect orientation surfaces" warnings.
- Reports a "Warning" for an intersection with an imported gbXML shade surface instead of an "Error" when creating the analysis model from a gbXML model and newly added floors.
- Reports a "Warning" for imported gbXML spaces that have overlapping surfaces or overlapping surfaces as well as incorrect orientation surfaces.

#### Daylighting

- Added a Uniform CIE sky type – the zenith illuminance used to calculate the lux levels is the same as for a CIE overcast sky although only the daylight factors are usually of interest with this sky type.
- New Analysis/Reports menu option Daylight Factor Ranges added to generate a daylight factor ranges report directly from Tas3D.
- Bug fix – a crash was occurring if reflectance/transmission properties were added for a Building Element that had been created by merging two elements together e.g. a floor/ceiling combination when subsequently accessing the daylighting functionality.
- Bug Fix - now ignores NULL ceiling faces when calculating the position of the grid points at the working plane height above a floor i.e. if a space has been created with a height less than the working plane height but with a NULL ceiling.
- Bug Fix – some windows were omitted from the daylighting analysis when their perimeter was coincident with the surrounding wall or an adjacent window.

#### Bug Fixes

- DWG/DXF export was reporting an error (from release 9.3 only) unless a DWG import had first been executed.
- Windows in sawtooth roof were sometimes disappearing in the resulting analysis model

### Building Simulator

- NCM calendars no longer flagged as incorrect in the pre-simulation checks.

### UK Building Regulations 2013 Studio

- Now approved for the Welsh Building Regulations 2014.

- Unused internal conditions with schedules applied no longer cause the TBD file to fail an import into the studio.
- CO2 report was not including cooling.
- Issues with shell/core buildings resolved: In some circumstances, zones would be excluded from the actual but included in the notional, or vice versa – noticeable when floor areas differed between actual and notional.

## Visualisation

- Show/hide options reworked: 'Masked' surfaces are not filled with colour, and thus will not produce a tooltip when the user hovers over them. However, outlines will still be drawn (if outlines are enabled), as will flow arrows in the Result Viewer (again, if enabled).
  - Mask Transparent Surfaces will mask all surfaces with a transparent construction applied or whose building element is Null.
  - Mask All Except Floors will mask all surfaces with an inclination greater than or equal to 135°.
  - Mask Facing Surfaces will mask surfaces that are facing approximately towards the camera, thereby allowing the user to see into the building. This will auto-update as the user moves the camera.

## Measurement Units

- Feet and inches display rectified in Xft Yin mode – previously was displaying “in” instead of “ft”, e.g. “5in 4in” instead of “5ft 4in”. This was a display problem only.

## Systems

- Made group properties more obviously available.
- Added duty exchangers and a heating only flag for exchangers.
- Added more detailed categories for results.
- Improved the flow capacity calculation to more accurately match flow rates to design flows in many circuits.
- User now has the option to enter their own calculated values for horsepower and fan efficiency into the ASHRAE fan power wizard.

## Utilities

- DOE importer (.INP) can now create TBD feature shades.
  - Support for a wider range of inputs for the DOE importer (.INP).
  - Tas to Solar-Computer export utility now available (German language only).
-

## Tas Version 9.3.1

### UK Building Regulations 2013 Studio

- Validation process completed. The UK Building Regulations 2013 Studio is now approved.

### Systems

- Added External Controller Type and removed Average, Minimum and Maximum Controllers
- Replaces the Lua code control with scintilla control.

### Building Simulator

- Summary Checks HTML now outputs UTF8 HTML files.
- 

## Tas Version 9.3.0

### UK Building Regulations 2013 Studio

- New utility added for Part L and EPC

### 3D Modeller

#### General

- DWG/DXF import has been upgraded such that files up to 2014 format can now be imported.
- It is now possible to use the 3D View Setup dialog with a 3D Plan Window to define a view for a standard 3D window or a daylight view window i.e. this is applicable for gbXML imported models.

#### gbXML

##### Export

- Exported spaces now reference a Building Storey
- Sets wall to be of type UndergroundWall if Building element has the ground flag set
- Exports Frame entity for Opening type, with frame width defined.

##### Import

- Uses name of Construction if available, referenced by Surface, instead of Construction ID for name of Building Element after import.
- Uses name of OpeningType if available, referenced by Opening, instead of Opening ID for name of Window Type after import.
- Sets frame width of window type if OpeningType has a Frame entity.
- Uses existing Building Element as defined with associated flags set e.g. transparent.
- Uses existing Window Type as defined with associated data other than height and width which is still imported from the gbXML file.

##### Bug Fixes

- No longer crashes if a gbXML file is imported that has a Building Storey with the name "Ground Floor".
- Corrected calculation for normal of imported polygon, when the polygon has many collinear edges.

- Corrected setting construction normal – it was reversed if adjacent spaces defined in non-ascending order.
- “Reverse geometry” option sometimes caused invalid 3D display.
- Spaces with long names caused crash when adding to gbXML import report.
- A zone would be deleted after import if a space was defined with the same name.

## Results Viewer

- New option is 3D Visualisation context menu: Colours | Out of Range Colours. When enabled, surfaces with data values beyond the scale range will be coloured to distinguish them from surfaces with data values within the scale range.
- 

## Tas Version 9.2.1.7

- German language option added to Tas. This is selected in the Language tab of the Tas Manager Settings dialog. Several windows have been slightly re-organised to allow German language to substitute for English.
- Old files that are opened through automation (e.g. through macros or Studios) are now evolved automatically, rather than prompting the user to do so manually.
- Remote desktop sessions can now use a dongle on the remote machine for licensing.

## 3D Modeller

### General

- There is now a Dimensions... option on the right hand button menu for selected window to adjust the position of the window.
- Shade fin surfaces may now be defined for analysis as Exposed, rather than always being Internal to a zone, dependent on the fin angle. A fin that is perpendicular to the containing surface will generate Internal surfaces whilst one that is parallel will generate Exposed surfaces. Fins with angles in between will generate both with the surface areas being apportioned appropriately.
- The grid is not displayed by default in 3D views.
- Windows (frames and pane if displayed) are now coloured as its containing wall or roof with colour by analysis option.
- Improvements to picking in a 3D view.
- In Colour By Analysis mode, the new default colour for Null Link surfaces is now lavender, to distinguish it from the inner side of surfaces (grey). This will only affect new files.
- 

### gbXML Import

- Frame width set by default to 50mm for imported windows
- New option (available on right hand mouse button menu for selected surfaces) to “Set Exposed” for imported surface when the surface has “unknown adjacency”. These are usually surfaces exported from Revit which may either be exposed or adjacent to an undefined space. An attempt used to be made to identify surfaces as Exposed when imported, but this calculation has been removed. This exposed status is kept if the gbXML file re-imported.

- New option to “Reverse” for imported surface. It is only available for spaces that have a “gap” error or “incorrect orientations” error where the gbXML surface has been defined with incorrect geometry. This reversed status is kept if the gbXML file re-imported.
- New option to “Reverse BE” for imported surfaces. This is similar to the “Reverse” option for walls in standard floors.
- For easier use of the above options, it is now possible to view by zones and colour by analysis in 3D views in non-analysis mode. This is only for imported models and if no standard floors have been created.
- Also colour by BE in 3D views in non-analysis mode, now colours only first side of the surface with respect to the construction applied in TBD
- Messages in Import report and Errors/Warnings dialog have been revised and some messages are indicated as INFO
- It is now possible to set the type of an imported window to be a group window type.
- If importing to create 2D floors, it is now ensured that a window created from full height glazing fits above floor and doesn't vanish in analysis view.
- Improvements for importing large gbXML files.

### **Daylighting.**

- The resulting lux levels on the surfaces from the current daylight calculation can be shown in the daylight view.
- For new models the default ground reflectance is now 0.2 and the default glass transmission is 0.8
- A warning is now displayed if a building element has secondary elements and either primary or secondary element is transparent as the daylight calculations will not allow for this.
- A warning is now displayed if the building or latitude has changed and there are daylight calculations saved for the t3d file.
- The check box to get saved analysis parameters for daylight calculations has been replaced with a button.
- Camera movement options for daylight view now have the same behaviour as standard 3D views.
- Previously the daylight calculation became more inaccurate the larger the dimensions of the model. This has now been fixed to be consistent no matter the model size. However calculations may take longer for larger models.
- There is now an option for the calculation grid for daylight to be oriented as the current building grid.
- There is also an option to disregard the reflectance of surfaces on the outside of a building or other surrounding buildings to improve calculation performance, but with some loss of accuracy. This gives the greatest benefit when calculating for a small part of a building.
- The daylight results dialog now has a Copy Results button. This will copy the contents of the displayed grid to the clipboard, ready to be pasted into a spreadsheet program such as Excel.

### **Building Simulator**

- Added Sizing only option to perform only the heating and cooling design sizing calculations without performing a full hourly simulation. The maximum loads will then be available for each of the zones.

- Pollutant can now be displayed in PPMW (parts per million by weight) or PPMV(CO2) (parts per million by volume, assuming pollutant is CO2) to give a better estimate of air makeup.
  - Pollutant generation similarly changed to allow volumetric generation.
  - This option is selected in the Units page of the Tas Manager Settings dialog.
- External pollutant value now defaults to 600ppmw (~400ppmv(CO2)).
- Browser buttons – much like an internet browser, a limited history is now maintained while a file is open, allowing you to navigate back and forward to recently-viewed items.
- Optimisations for links between items to speed up browsing – e.g. clicking view construction from a building element.
- Taskbar button now gives simulation progress feedback.
- Frost protection temperatures default to -50°C to ensure they are not being used unknowingly.
- New option on simulate dialog: Output surface solar data. This option ensures all exposed surfaces are output to the results file with internal and external solar gain data.
- Zone data groups created in the results file during simulation now include all surface data relevant to zones in that group. This will only happen if any surfaces are output – i.e. using Output aperture data, Output surface solar data, or using surface output specifications.

## Result Viewer

- Visualisation
  - Surface colour options now chosen by drop-down list instead of right-click menu.
  - See below for universal visualisation changes.

## Systems

- Changed the way flow is calculated to be in step with the temperature calculation. This should help with VAV and complex water-side systems.
- Added If Controllers.
- Added Cont Controllers.
- Added Offset to Passthrough Controllers.
- Added MinFlow sensor for controllers to act like a thermostat sensor but for fresh air rate and current flow.
- Added PerPersonAndArea option for all flow sizing.
- Added ability to size flows for all fans, dampers and optimisers from nearest/attached zones separately from the zone flow and fresh air options.
- Added hourly per person and hourly internal condition options for minimum flow rates. These vary on an hourly basis.
- New a LoadComponent for adding miscellaneous loads.
- New direct absorption chiller components.
- Min and Max Offcoil temperature profiles added to Heating and Cooling Coils.
- Ancillary load profiles added to several plant components.
- Electrical load profiles added to desiccant wheel and airside exchanger.
- New simulation event for flow though the zone less than fresh air rate.
- Optimisers now have a design pressure drop that can be specified.

- Added No Minimum Flow option for Optimiser schedule mode. The minimum flow is counted as 0 when the schedule is off, otherwise it behaves normally.
- Evaporative precooling option for dry coolers.
- New option to turn off the simulation events during simulation.
- Improved group properties for zone components.
- Added Open TSD and Open TBD options to the tree.
- Support for 90.1 2010 methodology in ASHRAE Fan Power tool.
- Improved copying from the results window.
- Many fixes and other minor improvements.

### **Systems Wizard (TPDx)**

- New setups and control logic for 90.1 2007 baseline systems.
- New systems available: Fancoil with grouped mechanical ventilation, baseline systems 9 & 10.
- Improved VAV systems logic with better handling of dampers and fan turn down.
- SFPs, fan heat gains, exchanger efficiencies, and terminal flow rate are retained when switching between different system types. Selecting "Occupied and Unheated" or a baseline system deletes this stored data.
- PV and SHW Panels can be specified without zone surfaces.

### **Visualisation**

- Many optimisation changes, improving performance (especially during interaction) and reducing memory used.
- Surfaces can now be coloured by surface type, similar to "Colour by Analysis" in the 3D Modeller. Accessible by right-click menu in the Building Simulator and by the Display drop-down list in the Result Viewer.
- Surfaces can now be coloured by zone daylight factor. Accessible by right-click menu in the Building Simulator and by the Display drop-down list in the Result Viewer.
- Surfaces can now be coloured by sun availability, as seen in "Display shading information" dialog from the surfaces table of the Building Simulator. In the Building Simulator, this will be an average value for the whole year; in the Result Viewer this will be the value used for the currently displayed simulation hour. Accessible by right-click menu in the Building Simulator and by the Display drop-down list in the Result Viewer.
- Surfaces can now be coloured by Annual Insolation. Accessible by right-click menu in the Building Simulator and by the Display drop-down list in the Result Viewer. This is the amount of energy absorbed by an external surface throughout the year. This data is calculated on the fly rather than using simulation data. It does not account for feature shades, but does incorporate shading calculations as output by the 3D Modeller. If a building has less than a full year of shading calculations, insolation cannot be displayed. Surfaces with no construction applied are assumed to have an absorptance of 100%.
- Building Simulator only – selecting inter-zone air movements will highlight respective zones and also show arrows on the visualisation showing their start and end points (if one of these is external, and arbitrary outside point will be chosen). This replaces previous highlighting functionality. Please note that the arrows show only positions, not magnitude or schedule.
- Visualisation Options dialog now added for overlay data.

- This is now where the wind rose options are located.
- In the Result Viewer, the flow and wind arrow options are now located here also.
- Sun arcs show the position of the sun throughout select days of the year as projected onto a sphere surrounding the building. An analemma is the path plotted by the sun as seen at the same time of day throughout the year.
- In the Result Viewer, the sun position for the current hour can be shown, along with the sun position as used for calculating shading for the current hour.
- The solar map colours areas of the sky dome according to the amount of direct solar radiation that originates from the angle they face.
- The sky dome is simply an option to gain a sense of position when using other sun display options.
- Please see the Building Simulator and Result Viewer manuals for full explanations of the new features.

### UKBR Studio

- Sub-systems with different cooling efficiencies now separated on BRUKL document.
- When opening a TPLP file, if the source TBD file(s) cannot be located, the user is given the option to specify their location.
- External zones that are changed to non-external are now updated correctly when the source is updated.

### Utilities

- Support added for a wider range of inputs for the IDF Importer.
  - NHER Plan Assessor XML export can now produce version 5.4 files.
  - Added Batch simulation for TPD files.
- 

## Tas Version 9.2.1.6

- The first version of our Chinese language interface has been added. Choice of language is accessible through Tas Manager -> Settings -> Language.
  - Your computer must be set up to display Chinese characters. In the Region and Language settings, accessible through Control Panel, you should ensure that the following settings are set to Chinese (Simplified, PRC).
    - Formats tab: Format
    - Administrative tab: Language for non-Unicode programs
  - Other Chinese locales may work, but Simplified, PRC is recommended.

### 3D Modeller

- Daylight calculations. Calculate daylight factors and lux levels and display them graphically on 2D plan views. Output calculated daylight factors to the Building Simulator.
- Rendered 3D Daylight views. (Beta)
- By default, 2D Plan views in the 3D Modeller are now restricted to having one visible floor. This is the same as the input floor.

- Selecting a different floor in the floors sidebar will make that floor the only one visible in the current 2D Plan view.
- Selecting a floor that has not been started will bring up the 'Create New Floor' dialog, allowing the user to copy walls from another floor #.
- The 'Enable multi-select' button in the floors sidebar will allow the user to view multiple floors on a single 2D Plan irrespective of the input floor, just like it behaved in version 9.2.1.5.
- All 'Copy to input floor' style commands have been replaced by 'Copy to floor(s)' commands. The user will be presented with a dialog that allows them to choose one or more floors to copy to.
- The 'Purge Unused' command in the Zones dialog no longer removes empty zone sets.
- During export from the 3D Modeller, the default shading period is day 1 to 365.
- A new building element in the Building Elements dialog will now always have a unique name.

## Building Simulator

- 3D Visualisation changes
  - Tooltips now pertain to whichever surface is directly under the mouse pointer, whether it is transparent or opaque.
  - New right-click menu option: Show/Hide -> Show Transparent. Enabled by default. If disabled, all transparent surfaces are not drawn, and hence do not trigger tooltips.
  - New right-click menu command: Reset to Defaults. Resets all visualisation preferences to the defaults.
  - Compass now a nicer shape, not anti-aliased, scale calculated taking into account building height for a more appropriate size.
  - TBD files created by an older (~9.1.1) version of Tas had surfaces displaying the wrong way round in the visualization, and the North arrow off by 180°. This is now fixed.
- Substitute Elements can now accept values between 0 and 1, rather than treating all non-zero values as 1.

## Results Viewer

- 3D Visualisation changes
  - Tooltips now pertain to whichever surface is directly under the mouse pointer, whether it is transparent or opaque.
  - New right-click menu option: Show/Hide -> Show Transparent. Enabled by default. If disabled, all transparent surfaces are not drawn, and hence do not trigger tooltips.
  - New right-click menu command: Reset to Defaults. Resets all visualisation preferences to the defaults.
  - Compass now a nicer shape, not anti-aliased, scale calculated taking into account building height for a more appropriate size.
  - Colour scales have been altered for the display of results data.
    - The blue>black>red scale (used for displaying positive/negative variables such as relative pressure, building heat transfer, air movement gain...) has been enhanced to make the colours easier to read.

- The previous pink scale (used for displaying magnitude variables such as solar gain, ventilation, aperture opening...) has been replaced with a blue>pink>yellow scale, making the values significantly more distinguishable.
  - % signs now displayed correctly in tooltips.
- Export CSV now works correctly when commas are included in column headers.

## Systems

- PV and SHW panels can be added without needing an associated zone surface.
- New pipe heat loss component for heat exchange between fluid in a pipe and the ground or air.
- New surface water exchanger component for heat exchange between fluid in a pipe and a body of surface water e.g. a lake or pond.
- New Mitsubishi heat pump operation type, HVRF with BC box.
- New indirect absorption chiller type with additional heat rejection circuit.
- New ASHRAE fan power tool for setting fan power for baseline systems.
- Flow rate per m<sup>2</sup> option on SHW panels to allow pump sizing.
- Water use reported in the results added for humidifiers and cooling towers.
- Manufacturer Data Import Wizard. Additional Mitsubishi Electric components added. The range now includes Mr Slim, City Multi, HVRF, CAHV, Ecodan and Lossnay. The most recent catalog data is in the "Manufacturer Plant Data 2013.tpd" file.
- Manufacturer Data Import Wizard. Frenger chilled beam components added.
- The Edit -> Options dialog now allows the user to specify the paths used for the Manufacturer Data Import tool and the Borehole G-Function Import tool (see below).
- Vertical Boreholes include an 'Import' function on the 'G Function' tab. This allows the user to select from a number of pre-determined G Function curves based on the borehole configuration.
- Water Source Chillers have a new icon.
- New horizontal ground heat exchanger component for heat exchange between the ground and fluid in a field of parallel pipes.
- New water to water heat pump component.
- Free cooling option for water source chiller.
- New chilled beam with heating zone component.
- New water source ice storage chiller type.

## UK Building Regulations Studio

- HVAC section of the BRUKL document now displays correct notional auxiliary demand.
- Slinky Coils and Heat Pump components can no longer be selected.
- Criterion 3 report shows user-defined daylight factors, if applicable.

## Utilities

- Support added for wider range of inputs for the DOE (.inp) importer.
- New utility to allow BASF Micronal phase change material products to be modelled.

## Report Generator

- The Report Generator now includes a CIBSE Adaptive Overheating report that follows TM52:2013.
- 

## Tas Version 9.2.1.5

- Windows 8 now supported.

## Building Simulator

- Summaries report takes occupant sensible gain into account for calculating maximum occupants

## Results Viewer

- Condensation units are now shown as g/m<sup>2</sup> instead of kg/<sup>2</sup> - value is same, unit now correct
- External radiation now shows as W/m<sup>2</sup> instead of W

## Scottish Building Regulations

- Macro is using EPCgen and BRUKL version 4.1.e which means it can produce EPCs that can be lodged.

## UKBR Studio

- Studio is using EPCgen and BRUKL version 4.1.e which means it can produce Northern Ireland Part F and EPC documents
- Fan powers now calculated correctly for grouped systems (use correct peak heating and peak cooling values)
- SBEM Auxiliary Calc report now shows correct fan power density for grouped systems
- Chiller results now correctly retrieved for purposes of cooling SEER calculation on BRUKL report
- Auxiliary results now averaged correctly for aggregation on BRUKL report
- AHU-side heating and cooling coils now included for aggregation in BRUKL report
- Efficiencies on BRUKL report now correct when demand or consumption is 0

## Systems

- Steam humidifiers results graph report load correctly (previously showed RH reported as load)

## Systems Wizard (TPDx)

- Some component heating and cooling duties would not accept set values, only "Sized" – this has been fixed.
- Using the wizard to alter an open TPD document no longer reports the file as locked

## Report Generator

- Frequency and BB101 reports now use correct results periods regardless of which days were simulated
-

## Tas Version 9.2.1.4

### 3D Modeller

- Building Elements with a circular secondary element are now spotted and the chain is broken.
- Previously some documents were unable to be opened after running an operation on them through automation. This no longer occurs.
- Auto-assignment no longer happens for building elements already having a construction applied, or zones already having an internal condition applied.
- Active selections in sidebars forced into view so the user can always see their current Building Element, Zone, etc.

### Building Simulator

- 3D Visualisation
- Building Element and Zone colours can now be changed in TBD by clicking the colour box.
- Equipment gains now use Watts by default when using US units. As ever, they can be forced to Btu if desired using the option in Tas Manager.

### Results Viewer

- 3D Visualisation

### Systems

- Tas Systems has moved from being a beta version to a full release version. The file format is now fully supported.
- Manufacturer Data Import Wizard. Import Mitsubishi Electric components from the Mr Slim, City Multi and CAHV ranges.
- Project Wizard now allows users to create systems that use refrigerant circuits. The 90.1 Baseline systems can also be created.

### UK Building Regulation 2010 Studio

- Direct Electric systems no longer display an efficiency of 0 on the BRUKL report.

### 90.1 Studio

- Framework for undertaking the Performance Rating Method outlined in ASHRAE 90.1 Appendix G.

### Utilities

- New version of the IDF Importer utility.
- New DOE Importer which allows .INP files to be imported into Tas as TBD files. An example .INP file is included in the "sample projects" directory.
- New HP SSEEF SSEER Calculator. This utility calculates seasonal efficiency values for Air Source and Water Source Heat Pump systems. These values can then be used in the UK Building Regulation Studio. This allows manufacturer imported data to be included in Part L and EPC calculations.

### Licensing

- New dongle drivers must be installed. (Sentinel Protection Installer 7.6.5.exe)
- Network licensing now possible using existing Sentinel SuperPro dongles, provided they have network keys.
- Network licensing via HASP dongles implemented.

---

## Tas Version 9.2.1.3

### 3D Modeller

- The user can hold down the Alt button when using the 'Set zone' button. By doing this, the zone name selected in the zones table moves down by one. This allows the user to quickly apply multiple zones without the user having to select the zone name each time.
- The Building Elements table now has a Type column. If one of the default templates are used and the auto-assign option for constructions is used then constructions that share the same name as the type will be applied to the appropriate building elements.
- There is a new option on export to auto-assign constructions. If the default templates have been used and this option has been selected, constructions will be assigned to building elements as per the table below.

Element	Type
Items in Building Element table	<User Defined>
Shades	Shade
Transparent Wall Windows	Glazing
Opaque Wall Windows	Door
Transparent Roof Window	Rooflight
Opaque Roof Window	Solar/PV Panel
Shade or Window Frame	Frame

- The auto-assign constructions option will also generate and assign surface output specification containing solar gain to Solar/PV panel surfaces.
- There is also an option on export to auto-assign internal conditions. If the default templates have been used and this option has been selected, internal conditions will be assigned to zones based on their zone set.
- Show 2D zones 'names' and 'fill' options now work globally.
- Moving a DWG file while it was being used in the 3D modeller no longer causes the software to crash.
- An "unrecoverable error" no longer occurs when exporting a model with shadows where there is a window which equals the size of the wall or roof it was applied to.

### Templates

- The constructions in the default template names have changed to match the surface types in building elements. New constructions have been added.

### UKBR Studio

- Resolved an issue with "Mech vent with recirc" not simulating for very large zones.

## Report generator

- The report generator now checks to see if the TBD and TSD are open before running the calculations.
  - Fixed an issue in some reports erroneously reporting an error when choosing a start and end day other than the TSD start and end days.
  - Using "peak data" in frequency macro no longer causes an error.
- 

## Tas Version 9.2.1.2

### Databases

- There is a new NCMAactivities database called "NCMAactivities\_v4.1.4.tic".
- Internal condition 'Unoccupied and Unconditioned\_v4.1.4' has been moved to the 'Misc' folder of "NCMAactivities\_v4.1.4.tic".

### UKBR Studio

- The UKBR studio will not accept source TBD files that use "NCMAactivities\_v4.1" internal conditioned. The user should open the source TBD. Delete these internal conditions and replace them with ones from the "NCMAactivities\_v4.1.4.tic" Database.
- The heat recovery algorithm has been improved to prevent heat recovery turning on if that would increase the cooling load.
- Fixed issue where copying the HVAC Configuration for a system with SHW 'deletes' the SHW surfaces.
- 'Design Flow Rate' is now hidden for Supply Fans and cannot be changed.
- Speed for retrieving results from models with large number of zones using natural ventilation or extract only has been improved.
- Displaced Electricity displays correctly in charts.
- Issue with Building Address disappearing in certain cases is resolved.
- Zone names appear where appropriate on coils in Heating Circuit Configuration.
- The 'Retrieve Results' step is now *significantly* faster for large projects.
- Shades can no longer be assigned a building element type and so cannot affect average/max U-value checks.

### 3D Modeller

- Fixed issue caused by copying a window to another floor when the receiving wall was created in the opposite direction to the original wall.
- 'Export to Lightscape' option has been re-introduced.
- Gridlines are now solid by default, which increases drawing speed on some computers. The option to change them back to dotted lines can be found in the Grid Setup dialog.

### Tas Building Designer

- "A surface accounts for >49.5% of zone surface area" error will display zone number.
- Files evolved from the previous versions of Tas retain their daylight factor data.
- 'Optimum start' sizing option works if zones are set to 'design sizing'.
- Reintroduced the ability to drag a weather year over a design day to add weather data to the design day.

### Templates

- Templates use internal conditions from "NCMAactivities\_v4.1.4.tic".
- Telephone Exchange template has been removed as the NCM activity for Telephone Exchanges has been removed.

- Template 'Indust' has been renamed 'Industrial Process Building'
- A construction called 'SHW \ PV Panel' has been added to all templates.

## Report Generator

- Some reports did not work correctly when the TSD files involved contained less than a year's worth of data. This has been resolved.
- 

## Tas Version 9.2.1.1

### Tas Manager

- The TBT Template wizard is a new feature and accessible by clicking on the "Create Building" button.
- The "Create Building" button in Tas Manager, as mentioned above, no longer opens the 3D Modeller, which is has done in previous versions. The button now allows the user to select a template from which to create your building and also select a weather file.
- Currency unit now customisable through Tas Manager and uses system default unless specified otherwise.
- Essential Tas file types now forced into filter (though can be disabled if wished).
- The settings have a tab for selecting the template and database directories.
- Vista / 7 style folder browser added
- Folder dialogs now default to current folder selection when shown
- The Tas Manager is now resizable.

### Report Generator

The Report Generator can be opened in Tas Manager by clicking on the Create Report button. It includes several reports:

- Frequency
- Peak loads
- Annual loads
- BB101
- Part L Solar Gain check

### 3D Modeller

#### General

- There is a new 3D Modeller workspace.
- There are new default building elements – Roof and Exposed Floor will be assigned by default to the exposed surfaces of a space and the names "Internal Floor" and "Internal Ceiling" will be used to create composite names.
- Errors and Warnings dialog now resizable, sortable, and groupable.
- Window type placement can no longer be changed once the window is used in the model.
- Imported windows now interact correctly with window groups.
- The façade length of a space is now calculated to be the length of exposed walls at a height of 1.1 m.
- A floor element is no longer required for 'floating' external zones. You can leave the floor surface of any external zone as <null>

#### Bug fixes

- Prevent crash in zones model creation when merging walls if a very small polygon is created and the walls have windows
- Prevent crash in zones model creation when there is a wall that is not connected at one end with different heights at each end.
- Prevent crash when a full length window is placed in a wall that is not adjacent to a space on either side.
- Shading calculations – fix for very large polygon behind glass to receive internal shading correctly.
- Fix to prevent a window being moved when a copy of the window is made to be placed in a wall that has been drawn in the opposite direction to the original wall.
- A shade group can now be created with overlapping shades – previously this was only possible if shades in the group had different z offset positions.
- Fix to shadow display of shades and window frames – sometimes incorrectly displayed if partially shaded.
- Fix to display 3D view after Print Preview or export to .avi – occasionally view could not be refreshed.

### **gbXML enhancements**

- Imported windows now behave like standard windows for editing i.e. changing type and setting dimensions. The behaviour is as follows:
  - Changing a window type via the Window Properties dialog will now also change the dimensions. For example selecting by type and then changing to another type will also change all the selected window dimensions.
  - Using the Assign tool bar button for a window type also changes the dimensions
  - Changing the dimensions of the window type in the Windows dialog will also change the dimensions of the instances of that window. Note that you cannot change the dimensions of an imported window type only a newly created one.
  - The “Level” of a wall window is applied as relative to the floor to which the imported space refers to. Be careful as the floor level (taken from the gbXML file) is not always where you expect it to be.
  - An imported window type does not have a level defined. Changing from one imported window type to another does not change the bottom position of the window.
  - IMPORTANT –the above is dependent on the imported window having the same dimensions as the window type created for the window. A window type is created with the dimensions of the first window found. A subsequent window will have a dimension set to override (i.e. non-default) the dimensions taken from the type. To replace these with a window type with the same dimensions you need to use the “reset to default” button on the Window Properties dialog before changing a window type.
- Non-rectangular windows are now displayed correctly – note that a frame cannot be added to a non-rectangular window at present.
- Zone warnings indicate spaces that are not fully enclosed and highlights the edges where there is not a matching adjacent polygon. The errors distinguish between a space that has gaps between the surface polygons and spaces that may have incorrectly oriented polygons.
- Zone warnings indicate surfaces that have an unknown adjacency (when imported from a Revit gbXML file) and specify whether the surface have been assumed to be exposed or have a “NULL” adjacency with respect to the space.
- A non-ghost “Air-exposed” building element is created and assigned to exposed gbXML Air surfaces.

### **gbXML bug fixes**

- Improvements to import – spaces with “holes” e.g. columns.

- Checks for exporting windows when containing surface has a small area and/or resulting pane has too small an area (can occur if a frame is added to an imported window type) or frames have too small an area to export but panes are link surfaces.

## **Building Simulator**

- Ability to export and edit TBT templates.
- In previous versions of Tas, output groups were needed for buildings with greater than 300 zones in order to create multiple TSD files to avoid a single very large results file. Output groups are no longer needed, regardless of the number of zones and therefore should not be used for new projects.
- Files with output groups that are evolved from previous versions can continue to have output groups, if desired.
- Multiple constructions and internal conditions may now be dragged simultaneously from their databases into the tree view of the Building Simulator.
- Files are evolved 'silently' when opened by other programs (e.g. when Tas 3D exports and merges).
- Pre-simulation checks now all on one dialog rather than setup -> results
- Terminology fixes in summaries output.

## **Results Viewer**

- File format changed to remove file size restrictions.
- The TBD Output Groups should not be used for new projects.
- Graph control updated.
- Improved graphs with interactive legend

## **Systems**

- Psychrometric Chart now uses units.
- New results interface
- System generation wizard
- Generate a new systems project in the same fashion as in the UK Regs Studio
- Modify the active systems document by adding new systems and circuits

## **UKBR Studio**

- Some customers had reported inconsistencies with address details not matching between BRUKL documents and energy performance certificates or not saving when the EPC checkbox was not enabled. This has been rectified.
- HVAC Monitoring and Power Factor Correction factors are now applied where appropriate to direct electric heating. They are no longer applied to displaced electricity in the reports. (The BRUKL document values never had this problem.)
- Chiller fuel type limited to Biogas, Grid Supplied Electricity, LPG, Natural Gas or Fuel Oil.
- Shell and Core settings checked - systems may not be defined as 'N/A' in a Shell and Core building, nor may all systems be marked as Shell in an As Built Shell and Core building.
- In the BRUKL document, the Supply/extract SFP column in section 2.b now includes both supply and extract SFPs. The Exhaust SFP column is now left blank except for extract only systems, where the extract SFP is input as exhaust SFP.
- Correct boiler efficiencies now used by Notional building when the Actual building has a Grid Supplied Electricity boiler.
- Multiple TBD source files can be used.
- Multiple system configurations can be saved within the project file.
- Task management grid on generation page with intelligent task selection
- Better task scheduling and improvements for multicore systems

- Fix for raw data dump when a solar panel is present
- Can now use multiple source TBDs
- HVAC monitoring now on a per-system basis
- Zone and system name now shown on cooling page for individual coils
- Improved import to avoid certain bad TBD configurations causing issues at generation stage
- Improved handling of drag / drop on heating / cooling etc. pages
- Fix for studio occasionally not completely exiting upon the main window being closed
- Improved fan curve for variable flow fans
- Added timestamp to events on generation page
- Increased default tank size
- Cleaned up data in input report
- Changes to how certain systems are generated which have terminal units
- Can now have multiple HVAC setups in one file [but only one active]
- Displacement vent now heats outside occupied hours
- When certain input is irrelevant, it is now hidden to avoid confusion
- Moved “apply” and “cancel” buttons to top of lighting pane

## Databases

Changes to TCD include:

- The “Tools>Options” menu gives the user a choice of surface resistance to be used in the U-Value calculation. The options include the Tas default values, ASHRAE 90.1 and user defined.
- “Additional Heat Transfer” can be specified for the construction in terms of a percentage increase or decrease from the calculated resistance of the material layers. This change is reflected in the U-Value displayed for the construction. This factor can be used to allow for bridging effects or area effects.
- The “F-Factor” should only be specified for ground floor constructions. The exposed ground perimeter is calculated for each Zone. The first ground construction that has an “F-Factor” will be used to calculate the perimeter heat loss for the Zone.

Changes to 90.1 Constructions database include:

- 90.1 Constructions database including Appendix A and Baseline constructions.

Changes to TWD include:

- Wind Rose Tab
- Graph control updated.

## 90.1 2007 Baseline Generator

- The user can specify Climate Zone, Building Type and the 90.1 Construction database in the wizard and the constructions are assigned to the created Baseline buildings.

## Utilities

- BRE Daylight Factor Calculation

## Ambiens

- Undo/redo implemented. Undo marker made when items are added, moved, resized, deleted, or properties are changed. Also when items are pasted or domain properties are changed.
- Initialising the calculation clears undo markers.
- Vertices and gains can be moved by dragging them with the 'select' tool. This is only possible in design mode and is disabled when the simulation is running.
- When a wall is sub-divided with a new vertex, the properties of the old wall are copied to the new one.

- When an item or items are selected, they can be deleted with the delete key. (Exception: the last three vertices cannot be deleted.)
  - Mouse wheel zooms in/out.
  - Double-clicking middle mouse button does 'Fit All'.
  - When an action will invalidate the initialisation a message box warns the user. The action can be reversed with 'undo' in all cases.
  - When an item is pasted it is placed underneath the cursor's current position. Copied items may be pasted more than once.
  - Gains no longer need to be drawn from top left to bottom right corner.
  - Links between thermostats and walls/gains are drawn to the middle of the item instead of the corner.
  - Option to specify domain's starting RH (resets to 50% when file is reopened).
  - Inlet and outlet dialogs display total flow in/out.
  - Overview window updates when main view changes.
- 

## Tas Release v9.2.1

### UK Building Regulations Studio

- EPCs can now be produced according to 2010 regulations, using the Studio, and these can be lodged. All certificates will be watermarked, but an official presentation copy will be received once the assessor lodges the XML file.
- Zones using any of the following internal conditions are now not displayed in the Studio as they are not used for Part L:
  - Unoccupied and Unheated
  - Ware\_IndProcess
  - Prison\_IndProcess
  - C2\_Uni\_IndProcess
  - TM33
  - IEA 21c
- New "Multiplication Factor" for: air side systems; SHW; PV; and wind turbines
- New "Copy Runs" feature now included
- Re-colouring of zones in the T3D file, based on the system type applied to zone
- Updated NCM Activities database, v4.1.3
- "Fancoil Heating Only" system added
- Energain PCM support
- Improved validation throughout the Studio to reduce invalid configurations which would cause problems during generation
- New "Import Report" that logs progress on importing a TBD to a new project, including the new 'Best Guess' system that assigns building element and system types, at import, based on their name
- Improved file management resulting in faster responsiveness when working with large projects
- Tri-generational CHP added to Studio
- New reports added, including:
  - Data input report
  - System input report
  - Full result data dump
  - Solar gain check report
  - Zones and system assignment report

- “Report view” no longer shows “report processing was cancelled” when a large report is being generated (e.g. hourly)
- Interface fix for users with a high DPI setting
- Fix for an error some users were encountering with the U-Value screen
- Option for “Direct Electric” now fixed – previously this option would cause an error on TPD generation, requiring the user to select “Radiator” instead.
- Building element list is now sortable
- Lighting zone list is now sortable
- Lighting zone list is now able to show just zones (rather than in zone groups)
- Lighting is now configured with a side panel rather than a dialog
- Can now export all reports from a run in one go (right-click on the relevant node of the file tree on the left hand side)
- Improved handling of aborting tasks
- Studio now scans for running Tas applications before generation/simulation that could previously cause conflicts while performing these steps
- Only one instance of the Studio may be open at any one time
- Boiler editor now shows an approximation of carbon emissions at varying part load
- New chiller editor which is functionally similar to the boiler editor
- New control strategy for boilers chillers: “Staged: only first unit runs at part load”. This options will allow the first unit to operate at part/full load while forcing all subsequent units to operate at full-load only.
- “Renewables” screen now shows building element and area on surfaces
- Option to export a re-coloured 3D model with zone colour based upon output group or HVAC system
- Surfaces from multiple zones are now allowed on PV and SHW panels
- Pressing F1 or selecting “Documentation” from the Help menu will now open the relevant page in the documentation help file
- Fixed issue some users were reporting when running on multiple cores
- Better handling of memory, eliminating the “wait to close” that some users have experienced with large models
- Minor bug fixes and typographical corrections made
- While re-exporting the 3D model for the notional buildings (if applicable), feedback is given on the stage of export/shading calculations
- Demand, consumption and CO2 reports now include displaced electricity (and have had colours shuffled slightly)
- Reports comparing buildings now show the Reference building
- Save to/retrieve from registry options for certifier and employer details now work without requiring the user to manually edit each text field
- Lighting and equipment results now only retrieved for zones which have a (non-excluded) system applied to them
- Solar Conversion Efficiency is now named “Solar Conversion Factor”. The default value is now 1 instead of 0.2 (Default efficiency curve now flat 20% instead of flat 100% to compensate)

- For PV panels, the AC inverter is now sized by the Studio – it is no longer an input parameter
- You may now add recommendations to an EPC (shown in additional PDFs)
- All numbers in INP files are now rounded to an appropriate number of decimal places (mostly 2dp, but 0dp for areas and solar gain check percentages)
- Page validation now only notifies you about the first error it finds

## Macros

- The UK and ROI Building Regulations v3.5a macro and the Part L EPC 2006 Building Generator have been removed. If users modelled buildings for Part L2 at their design stage and want to use the same version for the "as built" stage, they must install that version of Tas, which can be found at:

**<http://www.edsl.net/install>**

- Scottish Building Regulations Macro and Scotland 2011 Building Generator have been added to model buildings for latest Scottish Regulations.
- Some users have reported ActiveX or component licensing errors when running the macros. These issues have been resolved.
- Problem with opening WFL files in weather utility macro has been resolved.
- Air Distribution Files in the Plant Modelling macro now have two new options. One is "Demand Control Ventilation" which allows the minimum fresh air rate to vary in proportion to the occupancy. The other option allows the heating occurring outside of the occupied period to be provided by re-circulated air rather than by a radiator in the zone.
- On the "Project Selection" dialog box of the Plant Modelling and Scottish Building Regulations, there is a new checkbox in the bottom left corner; if this is enabled then the macro goes into "debug" mode.

## Scotland 2011 Building Generator

- Updated for the Scottish regulations Section 6, 2010. Only to be used for Section 6

## Tas Manager

- Changed error message for Windows Vista / 7 users when application needs to be run as administrator

## 3D Modeller

- Full wall height windows now hide their 'height' field
- Window groups now always recalculate their size when modified, rather than only if they have been altered directly
- 'New Floor' now no longer requires a floor to be selected
- Secondary element can now be set to '<none>' successfully on elements which began with a secondary element
- Added selection of walls, windows and spaces in 3D Floors view and associated options on the right-click menu. Some menu options are not available in the 3D view as they are only applicable to the 2D view, i.e. for walls: Dimensions, Change/Attempt alignment, and for spaces: Display Heights and Edit Point heights

- New option on Select 3D Zones dialog – Highlight selected zones. If this option is set then the selected zones for the view are displayed with the rest of the model drawn in transparent grey, or solid grey if shadows shown.
- Model errors/warning dialog – added option to display errors/warnings in zoned areas only
- The zone name is now displayed in the model errors/warnings dialog (instead of repeating the text for each error or warning)
- DWG import/export libraries have been updated to handle DWG/DXF files generated by AutoCAD 2010
- There is a “Create” button on the Floors dialog that displays the Start Floor dialog so that multiple floors can be created by copying in one operation
- Select the floors in the Floors dialog list before using the Create button
- The Start Floor dialog now has an additional option to create an exact copy of a floor, i.e. not just the walls but the spaces and their attributes also. The “No initial copy” option has been removed and a Cancel button added. The Start Floor dialog is still displayed when a new floor is selected in the drop-down list
- In 3D zones view you can now highlight a space, wall or window and the building element, zone or window name is indicated in the status bar. Choose the relevant toolbar button as for selection in a non-zones view

#### **Models generated from gbXML files**

- Standard 3D Tas floors can be created to add additional geometry to an imported model, e.g. external zones with shading. The floors dialog shows both standard floors and the imported floor names. Select imported walls or spaces with a “Copy Null to Input Floor” operation to create the boundary on the new floor
- If a gbXML file has not defined any floors, a default floor is created for all spaces called <gbXML spaces>. This floor can be selected when using the “Select Floors...” dialog for a 3D view
- As described above, imported spaces and walls etc. can now be selected in a 3D view. Available options for each selection type are as follows:
  1. Surfaces i.e. walls, floors, roofs etc.
    - i. Delete – imported shade surface only
    - ii. Set Building Element
    - iii. Copy Null to Input Floor – vertical surfaces only. This is used in the creation of new standard 3D Tas floors as described above.
    - iv. Properties – this dialog allows Building Element selection and also displays the imported surface name, the name(s) of adjacent space(s) and zones and also the orientation and inclination that will be exported for analysis.
    - v. Edit menu –
      - a. Select All
      - b. Select by Type
      - c. Select Perimeter – useful for identifying surfaces to “Copy Null to Input Floor”. Note that a 3D View can be limited to display a single floor if floors are defined in the gbXML file.
  2. Spaces
    - i. Set Zone
    - ii. Copy Null to Input Floor – this copies the line of all vertical surfaces of the space. Note that this may not form an enclosed space on the Input Floor.
    - iii. Properties – this dialog allows the Zone selection and also displays the space name and description (if set in the gbXML file), the space volume and floor area.

- iv. Edit menu – Select All
  - 3. Windows
    - i. Delete
    - ii. Type/Dimensions – this dialog allows the window type selection and also new height and width can be set. Note that if a type is selected this does not change the dimensions of the window. Use the “Reset to default” button to use the dimensions shown in the Windows dialog. Note for an imported window these dimensions may not be the same as for the original imported window size if there are many windows of the same type but of different sizes.
    - iii. Edit menu –
      - a. Select All
      - b. Select by Type
- When displaying a 3D zones view and colouring by Analysis, the side of the wall, floor etc. facing into the space is now coloured grey. This is to indicate surfaces that have been imported with an incorrect orientation
- When highlighting an imported space, wall or window in a 3D zones view, the imported name is also displayed with the zone, building element or window name
- When a gbXML file is imported, there is now a check to determine if the space is fully enclosed by the given polygons. If not, an error is displayed in the gbXML import window and also in the model errors/warnings dialog. This does not mean that the space cannot be analysed but that the user should check the cause. The best way to do this is to display the zone in the 3D Zones view with no other zones displayed and colour By Analysis. This can be due to:
  1. a very small gap, in which case the model analysis can continue correctly. If a gap cannot be seen in a shaded view, sometimes viewing in wireline shows polygon edges that are nearly coincident.
  2. or to an incorrectly oriented surface. If the space is shown with no other spaces then all the surfaces should be coloured on the side facing away from the space, i.e. if a grey surface can be seen, then it is oriented the wrong way. This must be corrected in the originating software for the gbXML file.
- A gbXML file from Revit may generate an error for a surface indicating that “the same space is specified for both sides” and it is assumed to an exposed surface. This occurs when the gbXML file is generated for surfaces for which their adjacency cannot be determined. A surface may be exposed or it may be adjacent to another space. Looking at the surfaces in the 3D zones view and colouring by Analysis will determine any surfaces that are not exposed as assumed. Again this should be corrected in Revit

### **Building Simulator**

- Evolution of a TBD file now works properly when the file is opened from explorer (as opposed to by File->Open)
- New Lighting Function dialog, similar in scope to the new Aperture Function dialog
- When profiles are copied (aperture controls, IZAMs, internal conditions, &c) the setback value is now always correctly copied (previously only worked if the main value was of 'value' type)

### **Internal Conditions**

- When profiles are copied (aperture controls, IZAMs, internal conditions, &c) the setback value is now always correctly copied (previously only worked if the main value was of 'value' type).

### **Tas Converter**

- Removed dependencies and added unregister - should no longer cause a problem registering on install, or unregistering on uninstall.

### **Passivent Airscoop & Sunscope Builder**

- This new utility allows Passivent's complete range of Airscoop, Sunscope and Sunstruct units to be modelled using Tas Building Designer.
- Currently, for the Sunstruct unit only the light performance is modelled; the ventilation performance is not included.

### **Energain Thermal Mass Builder**

- This new utility allows DuPont Energain phase change materials to be modelled using Tas Building Designer.

---

## **Tas Release v9.2.0**

### **UK Building Regulations Studio**

- A brand new tool for Part L2 2010 projects.

### **3D Modeller**

#### **New Features**

- Option to resize windows to fit wall or extend to adjacent window. Available on right-click context-menu for selected windows.
- Option to have "Full height" window, i.e. like "Door" but to ceiling also, set when creating or editing window. The window shape is adjusted to meet the floor line and ceiling line of the wall; these may be sloping.
- The dimensions of placed window groups can now be changed in the Type/Dimensions dialog for selected windows. The width of wall group windows and both the height and width of roof group windows can be set.
- If a percentage of frame to a window is set, this percentage is now retained if the window dimensions are changed.
- The compressor for an AVI file can now be selected to get the best quality rather than using the default one.
- The DWG 3D export has been improved to output a single polymesh for a surface rather than many polygon fans and strips. This improves in particular the output for a wall or roof which has many windows.
- When opening T3D file and an error occurs when opening a referenced DWG file, the user is given the option to try again, e.g. to close the file if it is already open.
- The full DWG pathname is now displayed in the Drawings list.
- File dialogs now default to the current project directory: for open/save/import/export file dialogs.
- Menu: View | Remember dialog sizes -> Sizes of report list dialogs (floors, zones &c) and the columns within are stored in the registry and recalled by default. This menu item toggles this behaviour.
- Elements: Secondary element percentage now allows decimals, not just integers.
- Floors: New floors are now not ground by default - ground floors are after all a minority.

- Windows: New report dialog:
  - On the right side is a preview pane that should preview whatever you have selected or are dragging over.
    - If you have nothing or multiple things selected in the active report, nothing will be displayed.
  - Clicking 'New Window' will get you a default window immediately added to the list.
  - Clicking 'Edit...' will get you the traditional window editing dialog. This displays no extra information, but if many values need changing it may be easier to view this way.
  - Many columns in this dialog are hidden by default. The checkboxes at the bottom of the dialog will show/hide them as desired.
  - Clicking 'New Group' gets you a new blank group.
    - The old group creation dialogs are *no longer used* with windows.
  - You may drag a window or a window group to place it in a group. Simply drag one or more windows or window groups onto another window group (or one of that group's entries) to have it added.
    - By default all offsets will be zero, so there will often be overlaps before you change the values. In the preview, where multiple windows overlap, an area of wall (or floor) will be shown instead. Move the windows to sensible positions and it'll be fine.
    - If you drop something onto empty space in the groups report, a new group will be created automatically.
  - The 'Delete' button (and if you press Delete on the keyboard) on the groups report can be used both for deleting groups and also for deleting entries in groups.
  - 'Purge Unused' will delete all windows and window groups that have not been used in your model. See below for definition of 'used'.
  - The text for a window or window group will be red (if not currently highlight) and italic if there is a problem with it. Check that values are sensible, children do not overlap, wall and roof windows are not mixed in a group, &c.
  - The 'Used' value for a window or window group shows whether it is currently used somewhere in your model.
    - If the window (or group) is not itself used in the model, but is used in another window group which itself is used in the model, the 'Used' checkbox will have a small square mark instead of a tick. These items will not be deleted in a 'Purge' operation.

## Bug Fixes

- There is now a check for empty groups when deleting child window types and an error message is displayed.
- The materials in a roof construction are no longer reversed when a NULL floor is placed on top, i.e. usually when the NULL floor is for an external space used for positioning a roof shade above the roof.
- The intersection of planes defined on different floors is now calculated correctly to create the construction line.
- Error messages corrected for when positioning wall windows in roofs and vice versa.
- Shadows are never displayed if any setting in the Select Display dialog is set to transparent or wireline. The setting for gbXML shades is ignored if not available
- A snap angle of < 5 degrees is no longer allowed on input.
- Display floor heights option is now disabled if selected spaces are external.
- Sun position checks now for maximum day 365.
- Roof shades placed between floors were incorrectly aligned in zones view, i.e. displayed differently from the floors view.

- Group shade is highlighted if type is set current (rather than the child shades being highlighted if type set).
- The select shade button now stays set after selecting shades by rectangle
- The current dimension settings are now retained when many windows are selected for Type/Dimensions option i.e. a type can be set and any non-default width or height values are not changed.
- gbXML export - Added Storey name and level to exported file
- Fix to vertex highlighting and snapping for mapping to drawing and setting up grid for imported DWG/DXF file.
- Fixes for imported DWG/DXF files with rotated views.

## Building Simulator

- HVAC groups now referred to by name, not number, in left hand panel of the HVAC group editor.
- HVAC group names can be changed in the right hand panel of the HVAC group editor.
- Zone groups have new sizing options - the zone group list views have changed to reflect this.
- Aperture function dialog: You can have functions not controlled by zone temperature that work correctly.
- You can now run heating and cooling design days and dynamic simulations simultaneously and output heating and cooling design day results to the Results Viewer.

## Results Viewer

- You can now output heating and cooling design day results to the Results Viewer.
- 

## Tas Release v9.1.4.2

### 3D Modeller/Building Simulator

1. Fixed a shading bug where a transparent surface could not absorb solar gain at its external surface if positioned between an internal and external zone and exported with internal shadows calculated for that surface.

### Plant Modelling v3.3

1. When working in Imperial (English) units, SFP values are now displayed in W/cfm rather than Btu/cfm. The user has the option of overriding this setting in Tas Manager.
2. Fixed a bug in the Flow\_Sizing worksheet where the wrong temperature limit could be displayed if no room cooling was detected.

### Energain Thermal Mass Builder (Beta)

1. The installation now contains a Beta version of the new Energain Thermal Mass Builder for adding Energain Phase-Change Materials (PCM) to a Tas model.
-

# Tas Release v9.1.4.1

## 3D Modeller

### User-interface changes

1. The view combination selection within the Display Settings dialog box now has combo-boxes instead of radio buttons.
2. In the Display Settings dialog box, you may now choose the view type of imported 3D shades (if you have any) in the same way as you are able to change the view type of walls, floors and ceilings.
3. In the Display Settings dialog, you have the old choices of "Shaded", "Wireframe" and "Not Displayed", plus the new choice of "Transparent".
4. On the top toolbar, in addition to the "Wireframe" and "Shaded" buttons, there is now a similar button, "Transparent". This makes all surfaces (not windows or regular shades) translucent.
5. The Analysis Colours dialog has a new section for changing the analysis view colour of imported gbXML shades (if the model has any). This is orange by default.
6. In Tas 3D, the shades dialog has been somewhat revamped - radio buttons to select number/spacing, rearrangement, controls hiding when not used (388)
7. In the 3D Modeller, in the new shade dialog: The labels for the 'offset' fields have been changed. Their functionality has also been changed. If the radio button is set to 'number of fins', when you change the offset the number of fins will stay the same and the spacing will adjust. If instead you have 'fin spacing' selected, the spacing will stay constant and the number of fins will adjust.

### gbXML Import to create “Hybrid” 3D model

- 1) The gbXML Import dialog box has changed.
  - a) Zones tab –
    - i) The 2D floor creation is now available as a button on the zones tab.
    - ii) There is no longer the option to ignore zones in a gbXML file and zone by space name.
      - (1) If a gbXML file has zones defined, then their names are now always used to create/merge with zones in the 3D Tas file.
      - (2) If a gbXML file does not have zones, then the space names are used to create/merge with zones in the 3D Tas file (e.g. a file from Revit Architecture).
      - (3) The only reason for using the Spaces radio button when zones are defined is so that spaces can be selected in conjunction with display options on the Display tab.
      - (4) There is no reason to select zones, hence the list box is greyed out when displaying zones.
  - b) Display tab – the options have changed: space boundaries were added at Revit 2010 and can be displayed. Openings can be optionally displayed. These options exist predominantly for checking and debugging gbXML files.
  - c) “Direct export to TBD” tab has been removed and is no longer available – the user should import to create a hybrid model instead.
  - d) The “Create 3D Model” option on the zones tab is new and creates a “hybrid” model that can be saved to a T3D file, so that building elements and zones can be assigned (see picking/assignment in 3D views, below), views with shadows can be displayed and exporting with shading calcs is made possible.
- 2) Using the “Hybrid” model

- a) There is now an option to include gbXML shade polygons for shading analysis on export to TBD; available if polygons exist in imported model.
- b) For an imported model the building element width entry is currently disabled.
- c) An imported window can be edited to have a frame and an offset.
- d) If the offset is inwards, then the “wall” overhang polygons are shown. This is also included in the shading analysis.
- e) If you assign a different window type, then the geometry does not change but the type will be used in TBD.
- f) Non-rectangular openings are not drawn as such – they are imported to be the equivalent rectangular size.
- g) You can edit a window type and enable Internal Shading and define a frame but you cannot edit the width and height.
- h) Note that the imported walls, etc. will have a zero width so if you give a frame a depth it may protrude outwards relative to the wall.
- i) It is now possible to create a T3D file from an imported gbXML file, export to TBD and then subsequently re-import another gbXML file (e.g. with revised geometry) into the same T3D file, re-export to TBD and the settings for zones and constructions will be retained.
- j) If the original gbXML file did not have zones, then any zone assignments to spaces in 3D Tas will be retained if the gbXML space ID is the same in the file.
- k) Bug fixes for importing gbXML files from Ecotect. Window rectangular geometry is not included so dimensions were not being set on import for the window type. The dimensions are now calculated from the window polygon.
- l) In Bentley Architecture, two types of gbXML file can be created. A “Bentley–Tas” gbXML file will import to create a model with “thickness” to the walls, whereas a “standard” gbXML file is treated the same as a Revit one, i.e. you do not see any thickness to the walls, etc. At the moment the export and shading calculations should produce the same results whichever gbXML format is used.
- m) Export to 3D DWG now includes gbXML shade polygons

### **3D Views and using new Picking and Assignment feature**

- 1) The toolbar assignment buttons – Set Wall Element, Set Floor Element, Set Ceiling Element, Set Zone, Set Window Type, Set Shade Type are now available in a perspective view for use with a standard 3D Tas model or an “hybrid” model.
  - a) As in a plan view when in one of these modes, the entities that are assigned the current setting (RHS drop-downs, etc.) are highlighted in red.
  - b) You can pick only when a 3D viewing toolbar button is not depressed, i.e. pan, move camera, etc.
  - c) You can use the middle mouse button for panning and Shift + middle button will do a “Move Camera”.
  - d) When moving the cursor, a wall, window, shade or space is highlighted. Note that the Set Floor element and Set ceiling Element modes also cause the space to be highlighted – this is consistent with the 2D plan way of doing it, where you select a space. When you move the mouse to highlight walls, etc. and windows and spaces, the current assignment is shown and also for hybrid model the imported gbXML “name” is displayed, corresponding to the name assigned in Revit, etc. (Revit seem to have devised a good naming scheme for this purpose).
- 2) Colour by zone in 3D view is now available in Floors mode.

### **Rotated Shade Fins - New/Edit Shade dialog has been changed**

- 1) You can now enter a spacing value instead of the number of fins.

- 2) These values are related and entering one will update the other. This does mean that shades may no longer be symmetrical if a spacing value does not divide into the height for horizontal fins or width for vertical fins.
- 3) Rotation angle – by default this is 0 for horizontal fins and 90 degrees for vertical fins. This can now be set to between -45 and 45 for horizontal fins and 45 to 135 for vertical fins.
- 4) When the rotation is not the default, then the “Fit fins to shade dimensions” checkbox is activated. This option clips the fins to the rectangular area defined by the width and height and “wraps around” where fins are clipped, to add part fins.
  - a) For horizontal fins this means that if there are clipped by the top of the shade then a part fin is added from the bottom. This means that if then placed adjacent vertically that the fins would align. Similarly if clipped by the bottom of the shade.
  - b) For vertical fins the behaviour is the same but dependent on being clipped by the left and right of the shade.
- 5) Adjust width/vertical fins for alignment: this adjusts the width of the shade so that the horizontal fins of a shade will be aligned when placed horizontally adjacent. If there are no vertical fins then there is no further effect.
- 6) Adjust height/horizontal fins for alignment: this similarly adjusts the height of the shade so that the vertical fins of a shade will be aligned when placed vertically adjacent

### **Zones Model creation**

1. This now shows a message box so that the process can be cancelled. This means that the current zones model is used rather than creating a new one.

### **NHER Plan Assessor (Plan Assessor export utility) for SAP**

1. The utility produces an XML file based on your 3D geometry for use with NHER Plan Assessor for SAP calculations.
2. The utility also produces a text file with basic details of each heat loss floor in the model for use with the NHER u-value calculator.

### **Building Simulator**

1. When viewing a list of zones, sorting by Daylight Factor or Convection Coefficient columns can now be sorted properly.
2. When viewing a schedule, selecting cells and pressing “delete” now sets them to zero, just as if zero (0) was pressed.
3. When viewing a schedule, selecting cells and pressing zero (or indeed delete) now actually sets the cells to zero, rather than setting the displayed values to zero but internally setting the selected hours to one.
4. In the Aperture Function Wizard, in "choose functions by mnemonics" mode, choosing ZDWON now properly selects ZDWON.

### **Tas Manager**

1. Liquid flow rate (only seen in the Plant Modelling macro) in non-metric mode is now gal/min instead of gal/s.

### **Plant Modelling v3.3**

1. VAV fan now uses part-load fan characteristics, as described in Appendix of ASHRAE 90.1 2007.
2. There is now a temperature optimiser cut-off option for recirculation air systems. When the outside air temperature is greater than or equal to the temperature optimiser cut-off,

then the temperature optimiser behaves as a standard mixing box. The cooling loads may reduce or increase, depending on the weather file.

3. There is now a VAV supply temperature reset option. The user may now enter a secondary temperature to heat and cool to when the calculated flow rate for a given hour is below the fan minimum turndown. These off-coil temperatures are closer to the room set-points than the standard off-coil temperatures. Calculated heating and cooling consumption should be lower when using this option. The fan power may increase as the flow rates increase and the delta Ts reduce.

### **Changed pump options**

1. Constant flow pumps without bypass: this behaves the same as the “constant” option in previous versions of the macro.
2. Constant flow pumps with coil bypass: At peak demand behaves the same as constant flow pump without bypass. At part load, the pump rides the pump curve and consumption will vary. The results should be lower than when using the constant flow option.
3. Variable flow: This behaves the same as the “Variable” option in previous version of macros.
4. New parameter: Flow Return Delta-T.
5. New calculations take into account the fact that the density of water changes at different temperatures.

### **Boilers and chillers**

1. Boilers now have same part load options as chillers.
2. Hot Water Supply Temperature reset. When the outside temperature is at or below the design temperature, the boiler’s efficiency is as entered by the user. When the outside temperature is at or above the reset temperature the boiler’s efficiency is 1.5% more efficient than entered. If the outside temperature is between these two user-defined values, then the improvement to efficiency of the boiler is interpolated.
3. Chilled Water Supply Temperature Reset. When the outside temperature is at or below the user-defined design value, the chilled water supply temperature is set to the design value. When the outside temperature is at or above the user-defined reset value, the chilled water supply temperature is set to its reset value. In other cases, it interpolates the value. For every 1F difference between the design temperature and the chilled water supply temperature at a given hour, the COP of the chiller improves by 1% for the user-defined value.
4. The user has the option to enter the minimum return water temperature for water side cooling. A higher value means a lower cooling tower fan energy. The value does not affect the Condenser pump energy.
5. Condenser fan energy separate from cooling. The user enters the energy used by the fan as a proportion of the total chiller consumption at part load. The larger the part load percentages, the larger the Condenser fan energy. The cooling consumption will reduce by the same amount as the Condenser fan energy will increase.
6. Fixed issue with using electrical AHU and room in fixed load mode causing an unrecoverable error.
7. Changed the heat rejection calculation to include the consumption of the chiller.
8. Cooling towers: parameter Condenser fan power ratio has been replaced with Fan Power Performance.

### **Part L EPC Building Generator**

1. There is now an option to model a Biddle Innovair system. If you click Biddle Innovair having pointed to Mechanically ventilated (Heating only), then you need to complete the Biddle Innovair Function Parameters dialog by entering:-

- Occupied peak flow rate (l/s/m<sup>2</sup>)
- Night flow rate (l/s/m<sup>2</sup>)
- CO<sub>2</sub> lower limit (ppm)
- CO<sub>2</sub> upper limit (ppm)
- Previous day peak temperature (degrees C)
- Delta T cut-off (degrees C)
- Outside cut-off (degrees C)

## UK and ROI Building Regulations v3.5a

1. Changed the default fuel for DHW to oil
2. Changed the Notional fuel type such that if the DHW uses gas, then the Notional heating and DHW uses gas.
3. Added a Biddle function in the list of air handling files. The Biddle is compared to a mechanical zonal heating system. The Biddle has a terminal fan and an extract fan but no fresh air fan. It does not ask the user for an air change rate as this is read from the results.
4. Fixed a problem with some of the details tabs not disappearing when selecting BRUKL only.
5. Fixed bug in reading Plant Simulation and Sizing project files. Pre-2008 files could not be opened or simulated
6. Fixed an issue with Building Type. Previously, it was setting the value back to "office" when the user re-opened their project or ran the calculations.
7. DHW now follows the occupancy pattern rather than the ventilation schedule. This will not change the DHW consumption or CO<sub>2</sub> from results outputted in previous version. This change will ensure that the DHW does not turn on when the Biddle system is providing night cooling.

## Tas Release v9.1.4

### UK Building Regulations Macro

- Macro uses version 3.5a of EPCgen, BRUKL, BERgen and BRIRL generation programs.
- New sequencing option for heating unit. The user can enter a boiler that only operates at part load and have backup boilers that only operate at full load.
- New parameter in Details dialog called "Transaction type" when running UK EPCs.
- User now must selected from a range of options for the "related party disclosure" parameter in the Details dialog.
- Air Distribution system known as CAV has been renamed "CAV with recirculation Air"
- Air Distribution systems known as "Displacement Ventilation" has been renamed "CAV (all fresh air)"
- New air distribution system for modelling displacement ventilation systems with recirculation systems.
- New air distribution system for modelling Weatherite systems

### Plant Modelling Macro

- New options for cooling. User can now enter different COP for External Dry Bulb Temperature, External Wet Bulb Temperature or by Month.
- Cooling tower fans and condenser pumps can now be modelled.
- Wet or Dry side free cooling can be modelled.

## Databases

- Version 3.5a of the NCM Activities database is installed as part of this release. The internal conditions from this database should be used for all new PartL2\EPC Projects.
  - Version 3.5a of the NCM constructions database is also installed as part of this release. Please ensure that in Step 5, Part L2 EPC Building Generator, the utility is pointing to this new database.
- 

## Tas Release v9.1.3.1

### General

- It is possible to evolve all previous, new generation (i.e. 9.x.x), files to the latest format using Tas v9.1.3.1. Previously, the evolution process evolved files only one file format version previous.

### 3D Modeller

- The bug that caused T3D files to become corrupt on deletion of one or more empty window groups (i.e. if each component, or 'child' window from a window group was deleted, then the window group would be classed as 'empty') has been fixed.
- Application opens faster in automation (i.e. through the Part L EPC Building Generator, for example). There is no longer a warning in relation to missing drawings, e.g. DWG files.
- There was previously an issue with gbXML import/export features; if the system was set to a locale using commas as decimal separators (e.g. most European locales), the process would not work correctly. This has been rectified.
- The thickness of external shades can no longer be set by the user.
- Shades now must have at least a frame or a single fin.
- The minimum width for any shade is now 0.1mm.
- Shading calculations, when using transparent building elements or windows with the 'internal shading' option selected in conjunction with external zones, have been updated.
- When 'default' walls are sandwiched between 'external' and 'non-external' zones, their orientation (i.e. side facing zone) is self-corrected to represent an 'external wall' building element.
- The user can no longer manually reverse building elements ('Select Wall' button > right-click wall) with respect to external walls or walls adjacent external zones; the outer side (represented by a red line) when using the "Set wall element option" will be always on the outside of the building and cannot be transformed.
- A bug has been fixed that was causing diffuse radiation to be incorrectly distributed between external zones.

### Part L EPC Building Generator

- The utility now includes support for building regulations in the Republic of Ireland and can be used to create the Actual (which used to be called 'Design' prior to this new release), Reference (UK Notional), Notional (UK Reference) and Typical buildings.

## UK and ROI Building Regulations v3.4a Macro

- The UK Building Regulations v3.4a macro is now called "UK & ROI Building Regulations v3.4a".
- The macro now includes support for building regulations in the Republic of Ireland. At the time of this release the software was going through the accreditation process for Ireland.
- Modelling of CHP now allows for sizing a CHP on the base load as well as Annual Load. It also allows the user to set the energy priority for the system.
- For CAV and VAV systems, the 'Central AHU Setpoints' have been renamed: "Off-coil temperature".
- Heating systems with their fuel type set to 'electricity' with an efficiency of 100% or less are now compared against a heating system using oil (i.e. with respect to the notional building), as required by the NCM Modelling Guide.
- Heating systems using electricity with an efficiency of greater than 100% (i.e. if you are modelling heat pumps) are still compared to a heating systems using gas, as required by the NCM Modelling Guide.
- An error now occurs if the user enters a central AHU flow rate that is less than or equal to the minimum fresh air requirement, as defined in the as-copied NCM internal condition.
- The macro will error if the user tries to select zones with 'inappropriate' internal conditions applied to them.
- FATVAV system has been removed from the Air Supply list in the Air Distribution File; VAV now has an option to have a terminal unit.
- Fancoil and radiant cooling have been merged into a single air supply type. There is now an option to model a terminal unit.
- Fixed issue with error when a zone is used in more than one Building Information File.
- The macro automatically uses the country regulation selected during the creation of the building files (TBD files for regulations buildings) within the Part L EPC Building Generator. It does this by reading from the XML file saved in your project directory the regulation that was selected.

## Constructions Database

- The International Glazing Database has been updated to version 17.1.
- The U-values and glazing parameters buttons have been removed. The U-values and glazing parameters now appear on the construction details window.
- The resistance of an opaque layer is now taken into account in the U-value calculation. Although there are opaque materials in the standard constructions database and NCM constructions, they are not classed as 'opaque layers'. Constructions that use materials from these databases will be affected by this change. Note, Tas does not use the U-Value in its calculation, so results from using constructions with opaque layers will not change.

## Building Designer

- There is a new option in the Tools menu, called “Pre-simulation checks”. The feature alerts the user to the fact they may have made possible mistakes in their model, which might otherwise have gone unnoticed prior to simulating.
- It is now possible to remove all internal conditions from multiple zones non-singularly and thus far quicker than in previous versions; this can be done in a zone list (either by selecting the 'Zones' folder or by selecting a particular zone group), select one or more zones and then right-click and select “Remove Internal Conditions”.
- It is now possible to remove all IZAM multiple zones non-singularly and thus far quicker than in previous versions - in a zone list (either by selecting the 'Zones' folder or by selecting a particular zone group), select one or more zones and right-click -> Remove IZAMs.
- It is now possible to remove surface output specs from all surfaces in multiple zones non-singularly and thus far quicker than in previous versions - in a zone list (either by selecting the 'Zones' folder or by selecting a particular zone group), select one or more zones and right-click -> Remove Surface Output Specs.
- The information displayed in a “Summaries” output (Tools – Summaries) has been revised. Unnecessary data has been removed, such as daylight adjustment, while new information has been incorporated, such as for which days have had shading data calculated.
- It is now possible to drag-and-drop Zone Groups onto each other in the tree-view and the Zone Group Zone list view. Dropping one Zone Group onto another Zone Group will add the Zones contained in the source Zone Group to the target Zone Group, that is unless the target Zone Group is ‘read only’ (created and exported from the 3D Modeller as a ‘Zone Set’).
- The Zone Group list view allows multiple Zones to be removed from the group by selecting them and pressing the ‘delete’ key.
- A bug has been fixed that could potentially corrupt TBD files and which prevented the tree-view from correctly updating once a material was dragged between two different constructions (and then deleted from the target construction).
- The behaviour for changing the Start day on the calendar has been updated. Instead of shuffling all day types along, it now moves the surpassed day types in order to complete the calendar from the end of the year. The user may have to amend these day types when changing the Start day.
- Zones are no longer re-numbered upon simulation.
- There was previously an issue with aperture control functions evaluating to the 'ZDCEM' function; ZDCEM includes any controls that used external temperature or zone pollutant control. The function string was generated incorrectly in that the 4<sup>th</sup> parameter needed to be transposed with the second-to-last parameter. This has been rectified.
- Aperture control function wizard: the user can now set the openable proportion of a window (stored as the ‘factor’) in the same dialog as setting other parameters for the control.
- Inserting items in a building file, i.e. TBD file (e.g. new building elements, aperture types, IZAMS &c) can now be done regardless of which item is selected in the tree-view. This option is, as before, accessible via a right-click on the tree view or by the menu item Edit->New...
- In the ‘surfaces’ table, there was previously a column header: 'Reversed'. This is now headed: 'Side facing zone'. Note, ‘internal’ implies that the material layer marked in the table as 'Inner' is decreed to be facing the zone. 'Outer' means that the layer at the opposite side of the construction is facing the zone.
- The Zone Group list view now displays whether the zones within the zone group are output and whether their heating or cooling is sized.
- In the Building Simulator and Constructions Database, the U-Value (and also R-Value) and Glazing Parameter grids are now displayed on the Construction pane; buttons for separate dialogs have been removed.

- In the Heating Plant Room Controls, the 'Optimum Start' and 'Frost Protection' parameters appear only when optimum start or frost protection has been selected.
- If a wind pressure co-efficient file is used, then these data now do not need to include information for all apertures. If an aperture does not appear in the file, then Tas defaults to using its only calculation.
- A zone's upper limit schedule and setback value are now used by the calculations. Previously zone upper limit used the same schedule as the zone lower limit and the setback value for the upper limit was ignored.
- The 'factor' column for thermostat is no longer displayed.
- The 'Zones' table now includes a column displaying daylight factors.
- IZAM values now display to six significant figures.

## Result Viewer

- It is now possible to drag-and-drop Zone Groups on to each other, both in the tree-view and the Zone Group Zone list view. Dropping a Zone Group onto another Zone Group adds the Zones contained in the Zone Group to the target Zone Group; this is true unless the target Zone Group is 'read-only' (i.e. created and exported from the 3D Modeller). The Zone Group list view allows multiple Zones to be removed from the group by selecting them and pressing the delete key.
- There was previously an issue with components that had long descriptions, i.e. descriptions over 2047 characters in length. Hovering over these in the tree-view meant that the program would unexpectedly terminate, as the tool-tip was not able to hold a large number of characters. This has been rectified.
- In the Results Viewer, the user can now manually change the TBD path.
- The "Export to Excel" feature now has an option to export in tabular sum data and an option for displaying the day and hour.

## SHW

- Building elements or windows used to represent SHW panels no longer have to follow a pre-specified naming convention and thus do not have to begin with "SHW\_". The user can assign an arbitrary name to such elements/windows.
- The SHW macro now allows the user to select which surfaces represent SHW panels. Only surfaces that have had their temperature and solar gain results calculated and output will appear in the list.
- Only zones that have been outputted to the results file appear in the zone list.
- In the SHW macro, an error will appear if the user selects only zones with no DHW load.

## PV

- The name given to building elements or windows used to represent PV panels no longer need to begin "PV\_". Any name can be used.
- The PV macro now allows the user to select which surfaces represent PV panels. Only surfaces that have had their temperature and solar gain results calculated will appear in the list.

## Macro

- Fixed an issue with the weather utility macro not allowing the conversion of .wfl files.
- 

## Tas Release v9.1.3

### UK Building Regulations Macro

- This is the new name for the “Plant Simulation and Sizing” macro when used for PartL2 and EPC generation. This version of the macro must be used for generating EPCs. You will not be able lodge EPCs created in earlier versions from 10<sup>th</sup> May 2009.
- When creating an EPC, this version connects to the Landmark website to check if you are valid energy assessor.
- There is a new section in “Details” for information regarding your Proxy Server. This is needed so that the EPC generator can check the Landmark Database
- There is a new section for the “Air Conditioning” questionnaire which part of the new XML file generated when the EPC is created.
- EPCs and BRUKL documents can be generated for Northern Ireland.
- VRFs are now modelled as fancoil systems with electrical heating. There is no separate VRF option.
- New fuel types for heating units, cooling units, domestic hot water and CHP.
- Option to mix heat pumps with back-up boilers.
- Air Distribution files have been simplified
- No longer outputs sizing data.
- No longer requires a Tariff file to be selected.
- Fixed Sizing is no longer an option.

### Plant Modelling

- This is the new name for the “Plant Simulation and Sizing” macro when for purposes of sizing and simulation. It cannot be used for PartL2 and EPC generation.
- VRFs are now modelled as fancoil systems with electrical heating. There is no separate VRF option
- The older versions of the Plant Simulation and Sizing macro are there for legacy purposes and should be used for generating “As Built” BRUKL documents when the “As Designed” BRUKL document was generated using that version.

### Building Simulator

- Function Wizards now work for Europeans - before there was a problem with different decimal point characters.
- Null elements may no long have constructions, apertures and substitute elements applied to them.
- You may now change the building element of a surface by dragging a building element onto it.

- You may now apply a surface output spec to a surface by dragging one onto it.
- New menu item - Tools | Summaries and Checks. This replaces the macro of that name - it outputs an html file which may be viewed in a web browser or Excel.

## Results Viewer

- New menu item - Tools | Export to Excel. This generates a CSV file of selected results data that can be read by Excel.

## 3D Modeller

- When creating a window, one can now choose to set frame by percentage instead of by width. This calculates the necessary frame width to achieve that percentage.

## Constructions Database

- Along with U Values, one can now see R-Values.
- Invalid constructions and materials now show the first apparent error on the same screen as their data, rather than only giving an error on simulation.
- Database may now be searched for constructions or materials by name or by property value.

## Macros

Turbines:

- Turbines may now have minimum and cut-off speeds set. They may also be given a multiplier, rather than making several copies of the same turbine.
- **Peak Loads, Peak Zone Loads, Annual Loads, Frequency and Thermal Comfort Prediction** now support English units.

---

## Tas Release v9.1.2

### Tas Manager

- Batch simulation improvements to allow individual simulations to be cancelled and to give feedback on simulation progress.
- The settings dialog now has a Localisation tab allowing the user to set metric or imperial units.

### Databases

- The “constructions.tcd” database has been updated.
- New NCM databases (NCM 3.3)

- Direct import of TMY2 and EPW files can now be achieved in the Weather database.

## Building Simulator

- Output Groups can be created using the output groups dialog.
- During simulation Zones in different output groups will be output to different results files. This is useful for large models whose results could not be output to a single results file due to size constraints.
- There is now a simulation progress dialog to provide feedback and allow a simulation to be cancelled easily.
- The calendar now has a shading data radio button. This button displays the days of the year that have shading data.
- The shading proportions can be viewed for individual surfaces.
- The simulate dialog has an option to output weighting factors to the results file. These are now required to be output for Part L and EPC calculations.

## 3D Modeller

- Automation interface added.
- Feature Shades horizontal and vertical fins.
- Construction line building element renamed to null.
- The remove floor / remove ceiling options have been removed. Now to remove a floor or ceiling the null construction is assign. This change makes the assignment of building elements consistent.
- The context menu for a selected space in 2D plan view now has the options to “Set Floor Element”, “Set Ceiling Element” and “Set Zone”.
- gbXML import and export improvements including the option to import a gbXML file and create a TBD file without exporting from the 3D Modeller.
- Include building element plan surface area in zone area for sloped floor surfaces.
- “Null” check box in the Building Element dialog allows the user to create a user defined null element. This element is used to differentiate a particular null element when exposed to the outside.
- The longitude correction parameter has been removed and separate longitude and time zone parameters have been added to the building dialog.

## Part L EPC Building Generator

- There is now an NCM Version number in the building generator xml file.
- There is now support for Northern Ireland.
- The building generator checks the t3d file to determine whether a Zone has the external flag checked. Zones with the external flag checked are not output in the results file.
- There is an additional step to allow the user to automatically rerun the shadow calculations for the entire year without External Zones and Shades. The newly exported file is then used for the notional, typical and reference buildings. There is also the option to select a TBD file to use for the notional, typical and reference. This can be set to the same as the source TBD file if rerunning the shadow calculations is not required.

### 90.1 Baseline Generator

- Rotates the model 0, 90, 180, 270 degrees and exports a TBD file for each without running the shadow calculations.
- Adds Baseline Building Elements.

- Reduces the proportion of vertical glazing to external wall area to 40% and rooflights area to roof area to 5% if required. The proportion is left unchanged for models that do not exceed these limits.

### **IDF Conversion Wizard**

- Enables IDF files to be imported into Tas. Three example IDF files are in the “sample projects” directory.
- 

## **Tas Release v9.1.1**

### **Macros**

- Thermal Comfort Prediction macro
  - This replaces the previously distributed PMV macro
  - Produces various breakdowns in tabular and graphical format of PMV (Predicted Mean Vote) and PPD (Percentage of People Dissatisfied) values based on simulation results and user-inputted parameters
  - Calculation compliant with ISO 7730
  - Also produces Green Star points values for New Zealand and Australia in compliance with section IEQ-10 of the Green Star Technical Manual
- Wind Rose macro
  - Can now take input from either a weather file or from a building file.
  - Gives choice of graph outputs – Surface, contour or radar.
- Frequency macro
  - Macro has been re-written to produce results quicker.

### **Plant Simulation and Sizing**

- The macro can produce EPCs for Scotland and Section 6 Documents.
- "% Improvement" values for groups on “Results” tab of excel output are now correctly displayed.
- Heating and cooling demand in is now displayed correctly on the BRUKL document when the VRF system is being used.
- An error message will now appear if an Activity that is not allowed to be used in Part L2 is used. This stops the BRUKL generation program from crashing. The following NCM activities are not allowed to be used by zones which are selected in the Plant Simulation and Sizing Macro:
  - Ware\_IndProcess
  - Uni\_Display
  - Uni\_IndProcess
  - Hosp\_CellOff
  - Stadium\_IndProcess
  - Prison\_IndProcess
  - EmgcySvc\_IndProcess
  - Workshop\_IndProcess
  - Dwell\_DomToilet
  - Dwell\_DomBed
  - Dwell\_DomBath
  - Dwell\_DomDining

- Dwell\_DomKitchen
  - Dwell\_DomLounge
  - Dwell\_DomCirculation
  - IEA 21c
  - Office\_NoInternalGains5day
  - Office\_NoInternalGains24/7
  - TM33
  - Office\_HighDensIT
- There is a new parameter in the “BRUKL\EPC details” dialog box called Assessor Key. When the user becomes a Level 5 Energy Assessor, CIBSE will provide them with this key. This key will remove the watermark from the EPC and recommendations document.
  - The EPC/BRUKL details screen will only display parameters that are needed for EPC or Part L2. E.g. “Building Stage” will only appear when doing Part L2 calculations.
  - Removed the energy consumption of the heat exchanger from the VRF system. This used to be added to the Fan consumption.
  - Fixed an issue with DHW being incorrectly calculated for sub-project containing zones on different occupancy patterns.
  - Fixed an issue with the "The % of total capacity column of the boiler table must add up to 100" error appearing erroneously.
  - Default Certifier Details are now stored in the registry. So the “certifier details” stored in the previous version will need to be re-entered.
  - Removed the option for "undefined" for the NOS level of building.
  - Fixed an issue where the temperature optimiser that was increasing the room heating consumption.

## Databases

- Calendar Database
  - SEC Schools SBEM has be renamed NCM Schools
  - University SBEM has be rename NCM University
  - New calendar called “NCM Standard”. When running PartL2/Section 6/EPC calculation, this calendar should be used instead of the standard or default calendar. Except in the case of schools and universities which use one of the calendars mentioned above. The difference between this calendar and the standard one is that this one includes public holidays.
- Constructions
  - There is a new version of the NCM constructions database. It is V3.2. This database should be selected in the building generator when requested.
  - There is a new version of the NCM activities database. It is Version 3.2.
  - There is a new database called the “International Glazing Database”. It contains glazing materials but not constructions or gas layers.
- Internal Conditions
  - The NCM Activities 3.2 database should be used when applying internal conditions to models used in Part L2/Section 6/EPC. The main difference between this database and previous versions is that this one takes into account public holidays.

## Tutorials

- The Getting Started Manual has been replaced by tutorials for 3D Modeller, Building Simulator, Results Viewer, Plant Sizing and Simulation and Macros.

## Building Simulator

- Changes to 'Simulate' menu item:
  - To run a standard dynamic simulation, choose Simulate | Dynamic Simulation.
  - There is now the option of resetting heating and cooling loads to zero before simulation.
  - All user input (file location, option to merge files) now takes place before preconditioning, allowing the user to make choices and then leave the simulation going.
  - To run a design day simulation, choose Simulate | Heating Design Day Simulation or Cooling Design Day Simulation as appropriate. You no longer need to have a design day selected in the list pane as the button is pressed.
- In the Profile editing window, problems with the grid have been rectified – It is now safer and quicker to edit cells in the grid, and the graph now updates with each change made.
- Summary panes (for example when the Aperture Types folder is selected in the tree pane) have been improved to show more information.
- The Substitute Element view now allows the user to choose the substituted building element using a drop-down list. Drag and drop still works as before.
- The IZAM view now allows the user to choose the source zone using a drop-down list. Drag and drop still works as before.
- Surface list (on a zone pane) now links to other related information:
  - Double-click an item in the Building Element column to be directed to the details for that building element.
  - If a surface links to another zone, double-click the Type column (where that zone will be noted, e.g. ->Zone1) to be directed to the details for that zone.
- Many more changes now prompt a save query upon exit – in the previous version, one could make certain changes to a building, close the program and it would not ask if they wished to save.
- Function wizards have been added and amended:
  - The aperture control function wizard now gives the option of the ZDCM function – a function to simulate mixed mode control with both pollutant and external temperature control.
  - There is now a wizard for lighting functions to represent manual and photocell control.
  - There is now a wizard for capacity control functions for heating and cooling emitters.
  - Function wizards now sanity-check parameters – upper temperature limits should be higher than lower temperature limits, for example.
- Day type selection boxes now have buttons Select All and Select None.

## Building Designer (General)

- Drag and drop functionality has been improved in several places to be more consistent.
  - E.g. one can now drag an internal condition from the list pane of the Internal Conditions Database.
  - E.g. one can now drag a zone into the zones or surfaces table or a zone group into the zone group table in an output selection pane in the Results Viewer.

## Tas Manager

- Batch simulation now works with TBD files using wind pressure coefficient files.
- Batch simulation now saves TBD files after simulation to preserve sized loads.

## 3D Modeller

- 3D graphics optimised for graphics cards supporting Open GL.
- 

## Tas Release v9.1.0

### Macros

- Building Generator added for the creation of Design, Notional, Typical and Reference buildings.
- Plant Simulation and Sizing 2.0 macro for the creation on EPCs.

### Building Designer

- Addition of Lighting, Pollutant and Ventilation functions
- 

## Tas Release v9.0.9e

### Tas Manager

- Batch Simulation capability. Select the TBD files in the listview, right click and choose "Batch..." from the context menu. Choose the number of TBD files you wish to run simultaneously, then click run.
- Cut, copy, paste functionality.
- Settings dialog to allow the user to specify the file extensions that appear in the listview.

### 3D Modeller

- New option when importing drawings. The user can select to import an image drawing file (Bitmaps, Gif and Jpegs). It is recommended drawings inputted this way have a 10 metre line drawn on them to define the scale. Tas cannot snap to points on an image drawing file. A view cannot be printed with an image backdrop at present.
- A construction line can be merged with any wall type on another floor when creating the 3D zones model.
- Now checks for windows in walls with a "Ground" building element and generates a warning.
- Either or both name and fill can be selected for indicating zones.
- When in zone fill mode the spaces in the current zone to be assigned are highlighted, including if <none> is selected.
- All sets can be selected in zone selection for view i.e. all current zones in view can be cleared rather than going through each zone set.
- The "Select Floors..." option on the View menu now works when you are in Zones view mode; i.e. if you select one or more floors then the spaces on that floor are shown and

- the selected zones are ignored. To revert back to selection by zones just go to the option and select OK in the dialog (and vice versa for selection by floor).
- A new toolbar with buttons to create a new plan and a 3D view, switch between floors and zones in 3D view and corresponding accelerator keys ALT B and ALT F and toggle display of drawing CTRL H.
  - ALT R accelerator key for Select by rectangle
  - If a DWG file is not available in a run then the reference is no longer lost. It can only be removed using the Tools/drawings option and then a confirmation is required.
  - Middle mouse button double click provides Fit All function for 2D and 3D views.
  - Refresh in plan view will now update any corrected errors.
  - Remove ceiling and remove floor options can be used on any group of selected spaces irrespective of their current setting. When removing a ceiling or floor, a tick will only appear beside “remove ceiling” or “remove floor” in the selection pop-up menu if all selected spaces have had their ceiling or floor removed. If no tick appears and then the option is selected then the ceiling/floor will be removed from all spaces irrespective of current setting. If a tick does appear and the “remove ceiling”/“remove floor” option is selected then the ceiling or floor will reappear.
  - Various changes to gbXML Import including:
    - Messages and errors from import now displayed in a window
    - Allows for more than one ceiling surface for a space i.e. for pitched roofs
  - gbXML export (primarily for import into Cymap)
  - The DWG export now also allows for a DXF file to be created – this is determined by the file extension used.
  - It can be a bit confusing to see the triangulated floor and ceiling polygons in an exported DWG/DXF file when then imported into an AutoCAD application, so you can now remove those surfaces from the export if you wish. If you use the dialog to select whether walls, floors or ceiling are displayed and request that floors and ceilings are not displayed; these settings are now checked in the export. You would need to be sure not to do this for an export to Lumen Designer.
  - Minutes are now included to set the time on the sun position dialog
  - There is an option on the View/Export menu to create a series of views for export to an avi file: changing sun position through a day, viewing from the sun position through a day, and circling a building.
  - The user is now asked to confirm replacing a TBD file and lose current settings

## Building Simulator

- Ventilation function wizard.

## Macros

- The macros are now compatible with in Office 2007.
- There are changes to the automation interface to allow for the creation of schedules and internal conditions programmatically.

## Frequency

- The “Display summary table” option has been removed. When the macro is run it will always create a summary table.
- If the user chooses to “display graphs”, a message will appear before running the calculations, warning them that a workbook will be created for each zone.
- “Start hour” and “end hour” parameters have been replaced. The user now selects a

- schedule instead.
- Schedules can now be created within the macro. When they are created, they are saved in the TBD file.

## Lighting Control

- The macro no longer gives an error if the selected TBD file does not contain a schedule.
- If you attempt to run the calculations without selecting an internal condition, a message box will appear asking you whether you wish to continue.
- Schedules can now be created within the macro. When they are created, they are saved in the TBD file.
- Changed the way that the lighting gain is calculated so that when parasitic power is used without a time clock, the parasitic power is used on all hours of the year not just on the hours of the selected day type.

## Part L2 / Plant Simulation and Sizing Macro

The PartL2 macro has been renamed. It is now called Plant Simulation and Sizing. The plant room, air distribution and tariff files are now stored in sub-folders in the current project directory. Any plant room, air distribution and tariff files that were stored in the \program files\Tas\macros subfolders are copied into the current project directory when the macro is run.

### Project

- There is a new drop down list with 3 options: "Plant Sizing and Simulation", "Part L2a for England and Wales" and "Section 6 for Scotland".
- The "Plant Sizing and Simulation" option allows the user to obtain peak loads and total consumption without filling out data specific to Part L2a and Sections 6. Therefore the user does not have to select a notional building, assign construction details to building elements, fill out the BRUKL details, select the system types for the BRUKL document, choose management features that are specific to the British building regulations or pick a COSP air distribution file. The graphs will only display results for the design building.

### Project Details

There is a new section called "Fixed Building Load Sizing". It has the following parameters:

- Heating/Cooling: if this option is checked, the zone heating/cooling loads are sized based on the "Zone maximum load" for heating/cooling in the TBD file rather than the peak heating/cooling load found during dynamic simulation. It also sizes the rest of the system based on fixed design criteria rather than based on the Peak values found when running the macro. If the sizing for heating/cooling is also outputted, it will display the peak values as calculated using this method rather than the peak loads calculated during the simulation run.
- Outside dry bulb Temperature: The central AHU heating/cooling will be sized based on this temperature.
- Outside wet bulb Temperature: This is used to calculate the humidity during the design day.
- Design Margin for central AHU (%): the size of the central heating/cooling AHU will be increased by this value.

### Central Air distribution:

- The data can be entered now in one of two ways: clicking on the details tab and filling in the values or clicking on the description button, clicking on the “set” buttons and setting up each part of the system separately.
- The “set” buttons are red when you open a central air distribution file. When you click on them, enter the data in the dialog box and then click on the “OK” button, the “set” button will go grey.
- If you try to save the air distribution file with an illegal value, the “set” button for the part of the system with the error will turn red and all the other “set” buttons will be grey.
- The heating coil before the mixing box in CAV/VAV/FATVAV system has been renamed “frost protection”.
- The air-to-air heat recovery has been split into two types: “with bypass” and “without bypass”. If the “with bypass” is selected, the heat recovery not heat the fresh air beyond the bypass temperature setpoint. It will not cool the air even if the fresh air temperature is higher than the return temperature. This is how the heat recovery worked in previous versions of Tas. If the “without bypass” option is selected, then if the fresh air temperature is lower than the return temperature, the fresh air will be heated. If the fresh air temperature is higher than the return temperature, the fresh air will be cooled.
- The “heating”, “cooling” and “optimise fresh air temperature” check boxes have been removed and replaced with a drop down list. If “Optimise fresh air temperature” is selected, the fresh air will be both heated and cooled. The cooling setpoint must be lower than the heating setpoint.
- The “CO2 based reduction” parameter used in Mechanical vent with recirculation has been moved from the supply air area to the fresh air area. It now reduces the amount of fresh air supplied by the percentage entered rather than the amount of supply air.

### Plant Room:

- The boiler part load characteristics file has been removed. The efficiency of the boiler at 25%, 50%, 75% and 100% have to be entered instead.
- Multiple boilers with different efficiencies and different sizes can be entered. The user must enter the percentage of total capacity that is delivered by each boiler. This must total up to exactly 100%. The boilers are used in order. When boiler 1, reaches capacity, boiler 2 will turn on, when boiler 2 reaches capacity, boiler 3 will turn on etc.
- Different boilers can use different fuels. “Fuel type” is used in the calculation of CO2 emissions. The macro will use the appropriate CO2 factor for each boiler.
- The cooling part load characteristics file has been removed. The efficiency of the cooling unit at 25%, 50%, 75% and 100% have to be entered instead.
- Multiple chillers with different efficiencies and different sizes can be entered. The user must enter the percentage of total capacity that is delivered by each chiller. This must total up to exactly 100%. The chillers are used in order. When chiller 1, reaches

capacity, chiller 2 will turn on, when chiller 2 reaches capacity, chiller 3 will turn on etc.

## PMV

There is a new macro used for calculating the Predicted Mean Vote (PMV) in accordance with ISO 7730 standards. It will output the percentage of the selected time period that each chosen zone is between a PMV of -1 and +1, -0.75 and 0.75 and -0.5 and 0.5. It will also output the percentage of time that the PMV averaged over the selected zones is between those values. For New Zealand users, it will also show the number of Greenstar points that zone has achieved according to "IEQ-10 – Thermal Comfort".

The input parameters are:

- **Zone:** The list of the zones in the TSD file. The shift and ctrl buttons can be used to select multiple zones. For each zone selected, a spreadsheet will be created with its results.
  - **Zone groups:** The list of the zone groups in the TSD file. If the user selects a zone group, the member zones will become selected in the zone list box. The shift and ctrl buttons can be used to select multiple zone groups.
  - **Metabolic Rate:** Metabolic Rate is a measure of the total amount of energy we produce when we perform different activities. There is a table of activities and their associated metabolic rates in the Appendix of the Ambiens Tutorial. This tutorial can be found in the "Tas->Tutorials" directory of the Tas Manager. The metabolic rate (met) is measured in metabolic units. 1 met = 58W/m<sup>2</sup>.
  - **External Value:** Due to the inefficiency of our bodies the total amount of energy we produce (Metabolic Rate) does not equal the amount of work we get out (External work). The rest of the energy is transferred into bodily heat production and that is the value we are interested in when assessing comfort and calculating PMV. External Work is measured in W/m<sup>2</sup> and must be less than metabolic value when measured in W/m<sup>2</sup>. External Work is zero for most activities. For more information on External Work or Metabolic Rate see ISO 8996-1990: Ergonomics: Determination of Metabolic heat production.
  - **Air Velocity:** The average speed of the air entering the space measured in metres per second (m/s).
  - **Clothing Value:** The clothing value (clo) is a measure of the thermal resistance of clothes. 1 clo=0.155m<sup>2</sup>C/W. There is a table of clothing ensembles and their associated clothing values in the Appendix of the Ambiens Tutorial.
  - **Start day:** The first day for which results will be displayed. This start day must be between 1 and 365. By default this value is set to the first day that the TSD has values for.
  - **End day:** The last day for which results will be displayed. This end day must be between 1 and 365. By default this value is set to the last day that the TSD file has values for. If the start day is after the specified end day, the calculation period will wrap around.
  - **Day type:** The day type for which results will be calculated. This is a drop down list containing the day types used in the TSD file. Multiple day types may be used in the same run of the macro, but a day type may not be included more than once.
  - **Schedule:** this determines the hours in the day that the results will be calculated for. There is a drop down list containing the schedule used in the TBD file. The user can create additional schedules in the macro by clicking on the "Create schedule" button and filling out the data. Any schedule created this way will be saved in the TBD file.
-

## Tas Release v9.0.9d

### 3D Modeller

- The mouse wheel can be used to move around 2D and 3D views. Hold down the mouse wheel to pan, rotate the mouse wheel to zoom in and out.
- Windows and window groups can be copied in the Window dialog box (Ctrl-W). Select a window or window group then click on the copy button. If a window groups is copied, the windows that are a member of that group are not copied.
- GBXML files can be imported. Select "Import GBXML" from the "File" menu, pick a file to be imported and then follow the on-screen instructions. This new functionality is still in its early stages and we would be interested in any feedback. Please email any comments to [support@edsl.net](mailto:support@edsl.net)
- Added a new warning "Internal shading cannot be calculated unless adjacent to a zoned space". This means that the surface is using a building element that has the "internal shading" option checked and one of its sides is touching an unzoned internal space. To remove the warning, either uncheck "internal shading" option for that construction or zone both sides of the surface.

### Building Simulator

- An "Output" option has been added in the "zone group" details window. If the option is checked, all zones within the zone group will have their results outputted into the Tas Simulation Data file when a simulation is run. If it is unchecked, all zones within the zone group will have their results omitted from the Tas Simulation Data file when a simulation is run.
- The table in the "Zone groups" details window now has columns to show the maximum heating and cooling loads, whether the zone loads are being sized and whether the zone's results will be output.

### Databases

- The NCM activities database has been updated with the latest data provided by BRE.
- A new construction, "Notional External wall for section 6" has been added to the "EDSL recommended Part L2 constructions" folder of the NCM constructions database. It has a U-value of 0.30 and should be assigned to the "Notional Wall" element in the notional building when modelling for Section 6.
- A new construction, "Notional flat roof for section 6" has been added to the "EDSL recommended Part L2 constructions" folder of NCM constructions database. It has a U-value of 0.16 and should be assigned to the "Notional flat roof" element in the notional building when modelling for Section 6.

### Notional Building Generator Section 6

- There is a new macro called “Notional Building Generator section 6”. It is used to create the notional building when calculating CO2 emissions for Scottish buildings. It works in the same way as the “Notional Building Generator 2006” except the user selects those elements which represent “high usage entrance doors, display windows and similar glazing”. This ensures that the notional building has the same surface area of these elements as the design building. The other difference is that external surfaces that are less than 10 degrees from the horizontal are replaced with “Notional flat roof” and external surfaces that are between 10 degrees and 70 degrees from the horizontal are replaced with “Notional sloping roof”. All roofs then have 20% of their surface area replaced with glazing.

## Part L2 Macro

- There are new management features in the VRV air distribution file and the Plant Room specification file. They are called “lighting voltage reduction management scheme” and “Natural ventilation control designed to achieve an occupied period temperature always less than 28C” These are specific to Scottish building regulations section 6 and should only be used if the building being modelled is in Scotland.
- The latest version of the BRUKL document is output. This version highlights in red any element that fails the U-value check and any system that fails the systems check.
- There are new parameters for the BRUKL details dialog box:
  - **Country:** If “England and Wales” is selected then a BRUKL document will be outputted. If “Scotland” is selected then the “Scottish Building Regulations Section 6 Guidance” document will be outputted.
  - **Building Type:** Select the appropriate type for the building being modelled. This option will change the target U-values for Check 2a of the “Scottish Building Regulations Section 6 Guidance” document. This option will only be enabled if “Scotland” is selected as the country.
  - **Building is designed and built following the guidance in Accredited Construction Details (Scotland):** Currently this option does nothing and only appears when “Scotland” is selected as the country.
- The “Fixed Building Services” section of the BRUKL document as changed. For each Sub-project using a central air distribution system, the fan power will be output. For each plant room, the heating, cooling and DHW efficiency will be output. For each sub-project using a VRV systems the fan power, heating, cooling and DHW efficiency will be output. They will be labelled so the user will be able to tell which plant room/ air distribution/VRV file is being checked.
- Systems using terminal fans will have the fan power efficiency for terminal fans checked as well as the central AHU fan power in the “Fixed Building Services” section of the BRUKL document.

## LightingControl / DaylightAvailability

The DaylightAvailability macro has been renamed. It is now called “LightingControl”. The macro can now be used to calculate the lighting gain when using automatic presence detection (PIR) as well as daylight control.

When running the macro, first select the TBD file. The weather data, internal conditions, calendar and schedule will be read from this file. Select the type of lighting control that is to be modelled

and what internal conditions the lighting gain will be applied to. Select the time period when the lights could be on. The final section of the dialog box is called “Daylighting Graph setup” and only appears if daylight control has been selected. Once the dialog box has been filled in, click on the “Run” option. Graphs and tables will be output displaying the hourly lighting gain. If daylight control has been selected then graphs displaying diffuse illuminance within the space will also be output. If an internal condition has been selected then the calculated lighting gain will be assigned to it.

The macro has the following parameters:

**Automatic Presence Detection:** Select the type of PIR system being used. The hourly lighting gain will be multiplied by a factor appropriate to the type of system selected as shown in the table below.

Automatic Presence Detection	Factor applied to lighting gain
None	1
Auto On/Dimmed	0.95
Auto On/Auto Off	0.9
Manual On/Dimmed	0.9
Manual On/Auto Off	0.82

**Daylight Control:** Select the type of daylight control being used. The four options are described in the table below:

Daylight Control	Description
No Daylight Control	The lighting gain behaves independently of the amount of natural light in the room
Manual Daylight Control	When the natural room diffuse illuminance is below the target room illuminance then the maximum lighting gain is used. When it is above, the minimum lighting gain is used.
Photocell Control On/Off	When the natural room diffuse illuminance is below the target room illuminance then the maximum lighting gain is used. When it is above, the minimum lighting gain is used.  Parasitic power is then added to the hourly lighting gain.
Photocell Control Dimming	When the amount of natural room diffuse illuminance is zero, then the maximum lighting gain is used. When the amount of natural room diffuse illuminance is greater or equal to the target room illuminance then the minimum lighting gain is used. Between these two values the lighting gain is inversely proportional to the natural room diffuse illuminance.  Parasitic power is then added to the hourly lighting gain.

**Target Room Illuminance:** when the natural room illuminance exceeds this value, the lighting gain will be set to the minimum lighting gain value. If the natural room illuminance is below this value and Photocell Control Dimming has not been selected then the lighting gain will be set to the maximum lighting gain value. If dimming has been selected then the lighting gain is inversely proportional to the amount of natural light in the room

**Maximum lighting gain (W/m<sup>2</sup>):** the maximum amount of lighting gain allowed during the specified period.

**Minimum lighting gain (W/m<sup>2</sup>):** the minimum amount of lighting gain allowed during the specified period. This parameter only appears when modelling daylight control.

**Daylight Factor (%):** The room's natural diffuse illuminance on the horizontal working plane as a percentage of the external diffuse illuminance on a horizontal plane. This parameter only appears when modelling daylight control.

**Parasitic Power:** The amount of energy used by the lighting control system not including the lights themselves. The default for digitally addressable systems is 1W/m<sup>2</sup> and the default for stand-alone sensors is 0.3 W/m<sup>2</sup>. Alternatively, the user can specify a value for the system used. This parameter only appears when modelling daylight control with photocell sensors.

**Photocell sensor is on Timer Clock:** if this option is checked, the parasitic power is only added to the lighting gain on the hours selected by the user in the "Time Period" section of the dialog box. If it is unchecked, the parasitic power is added to the lighting gain for every hour of the year. This parameter only appears when modelling daylight control with photocell sensors.

**Internal Conditions:** The internal conditions that the calculated lighting gain will be applied to.

### Time Period

The user must set up which time period they want to see results for.

**Start day:** The first day for which results will be displayed. This start day must be between 1 and 365. By default this value is set to the first day that the TSD has values for.

**End day:** The last day for which results will be displayed. This start day must be between the start day and 365. By default this value is set to the last day that the TSD has values for.

**Day type:** The day type for which results will be displayed. This is a drop down list containing the day types used in the TBD file.

**Schedule:** The schedule for which results are displayed. This is a drop down list containing the schedules created in the TBD file.

### Daylighting Graph Setup

This section sets up the general details needed for creating the daylighting graphs. This section will only appear when modelling daylight control.

**Start Illuminance (lx):** Sets the first value for which results will be displayed.

**End Illuminance (lx):** Sets the last value for which results will be displayed.

**Show monthly graphs:** If this option is checked then the outputted spreadsheets will contain monthly charts for each month over the selected time period.

---

## Tas Release v9.0.9c

### Macros

- There is a new macro called "Summary and checks" which allows the user to output the TBD file's inputs into an excel workbook.
- The annual load macro now displays lighting gain, occupancy gain and equipment gain separately as well as totalled together in internal gain.
- The annual load macro now displays the annual loads for each zone in tabular form.
- The annual load macro has a new option which allows users to compare the total loads from two TSD files.

- The summary table in the frequency table has a new tab. This tab shows the peak temperature/RH for each zone over the selected period. It also shows the average temperature/RH difference between the zone and the outside over the selected period.
- The lighting control option in the daylight availability macro has been made easier to user. This is fully described in the “Getting Started” tutorial. The video has not been updated however.
- The Part L2 macro now outputs the latest BRUKL document which includes seasonal efficiencies. The users will now have to select the type of system they are using in each sub-project and plant room.
- If the TBD file is saved after the Part L2 macro is run, the user no longer has to re-assign construction types to building elements unless a new building element has been created.
- The Part L2 macro now has an option for modelling co-generational and tri-generational CHP. This feature is not documented yet but the parameters used are as described in the non-domestic HVAC Guide which can be found by going to this link:

[http://www.communities.gov.uk/pub/148/NonDomesticHeatingVentilationandAirConditioningComplianceGuide\\_id1500148.pdf](http://www.communities.gov.uk/pub/148/NonDomesticHeatingVentilationandAirConditioningComplianceGuide_id1500148.pdf)

- The Part L2 macro allows the user the option of not having Heating Water Pumps and Chilled Water Pumps in their design building when using a plant room. This allows for the modelling of systems such as DX split systems. The user will still have to enter a circuit length of these systems as the notional will have these pumps.

---

## Tas Release v9.0.9b

### All Tas

- Added a new folder in the NCMConstructions database called “EDSL recommended PartL2 constructions”.
- Added new calendars in the Calendars database for use in PartL2 calculations.
- Removed infinite loop in notional building generator 2006 when selecting a building element that is used internally for a personal door.

### Part L2 2006

- After discussions, it has been decided that the fresh air in the notional model should be heated and cooled to the same temperature as the zone’s lower limit. Previously it had been heated and cooled to the same conditions as the design model.
- Problem with reading the correct TBD when “assigning constructions with building element”. The information is now stored in a file named after the TBD and not the building name.
- Removed the management factors and replaced them with “Management Features” in line with the PartL2a document. You must re-save the plant room spec files and/or VRV spec file to use them.
- Removed humidification control as it was not part of CO2 emissions calculation.
- Added Domestic Hot Water.
- Added an option to set the Electric COP in the plant room spec file.

- The user must now set the Heating Circuit Length even if the using a pure electric heating system as the notional building uses pumps.
  - Removed an option to set the Fresh air fan SFP and check the fresh air cooling option from the air distribution file when a CAV or VAV system is being input. If these options have been previously used, the macro will ignore them.
  - Added schematics and descriptions for each type of system in the Air Distribution file.
  - Added an option to model displacement ventilation system in the Air Distribution file.
  - In the Air Distribution file, split VAV into two options; VAV and FATVAV.
  - In the Air Distribution file, split Fancoil into two options; Fancoil and Chilled Beams\Chilled Ceilings.
  - In the Air Distribution file, split Mechanical Ventilation into 3 options; Mechanical Ventilation, Mechanical Ventilation (extract only) and Mechanical Ventilation with Recirculation.
- 

## **Tas Release v9.0.9a**

### **All Tas**

- Changes and additions for performing 2006 Building Regulations calculations.
-

## Tas Release v9.0.8

### 3D Tas

- Inclined walls (sloping floors) - implemented by allowing floor heights to be assigned, and windows to be placed in floors.
- Create an isometric view from direction of the sun at given day/time - option on view setup dialog.
- Set Length of wall on input - RH button gives menu option when in wall input mode.
- Wall perpendicular/parallel options - RH button gives menu option when in wall input mode ,to be parallel or perpendicular to previously selected wall.
- Accelerator keys implemented for grid and angle snap - these options are also available on the RH button menu.
- Merge floors problems - major change to merge functionality that has fixed many problems.
- Infinite Loop on export - BE had itself as a secondary element, added check when creating BE.
- Problem applying plane to space with nearly co-linear walls - changed tolerance in plane calculation.
- Fatal error handler implemented in DWG file import, should stop crashes during import.
- Couldn't get out of select by rectangle mode if a zoom window command issued before the select rectangle completed, now fixed.
- Shading bug, shadows look different from different views- problem with windows in walls not on perimeter of the floor.
- When a door is the first in the window list and is included in a group, it was not setting the y offset to zero, and hence reported overlapping errors. Now fixed.
- All windows in group are now offset by the floor width if any one of them is a door.
- The point letters ABC in plane definition are now displayed when editing a plane and when it is selected to be used to calculate a height.
- Problem copying all walls to a floor - all windows were not copied - now fixed.

### Building Simulator

- Added new standardised internal heat transfer flags for TM33 ADL2 2006 accreditation.
- Added aperture control ZDWN without an outside air temperature cutoff.
- Two ventilation function types, tcmvc and tcmvn have been added to control ventilation based on zone and outside air temperature.
- There is now a 'Thread Priority' option to allow simulations to run at lower priority so the user can continue working more effectively with other foreground tasks (off by default, i.e. simulations will run as fast as possible).
- IZAMs, ICs etc. can now be dragged onto a selection of Zones in the Zone List View.
- All U value and glazing parameters are now calculated in accordance with EN410, EN673 and EN6946 as part of the new ADL2/TM33 requirements.
- Complete HTML help file TBD.chm now available via F1 (context sensitive) key press.
- Fixed problem to do with Internal Shading where a large number of zones with a small number of surfaces could result in an incorrect array size being calculated.
- Thermostat setback temperature can now be used for frost protection (was previously ignored as plant was considered to be 'off' when the schedule was 'off').
- Substitute element now works from Profile value not only schedule value as before. Any non-zero Profile value will force the use of the Substitute Element.
- There is a new cavity convection calculator included in the Gas Layer form. This will calculate EN673 (transparent) or EN6946 (opaque) compliant cavity values.
- IZAMs can now be copied quickly (like ICs and constructions) by dragging them onto the

- parent folder.
- New solar radiation check to ensure low radiation when the sun is lower than 8 degrees below the horizon.

## Result Viewer

- Complete HTML help file TSD.chm now available via F1 (context sensitive) key press.
- Now allow 12 variables to be displayed for a whole year on PCs with 2.5GHz or greater processors.

## Part L2

- Added new option for mechanically ventilated systems that allows the user to model systems that use recirculated air. The volume of recirculated air is sized based on the peak heating load and the supply air temperature is optimised to control the room temperature. No additional heating occurs in the room. Subprojects that use this system can only contain a single zone.
- The option to optimise central plant temperature has been removed. CAV systems and mechanical ventilation with recirc now always optimise the central plant temperature, all other systems do not.
- CAV now optimises supply air temperature for heating as well as cooling.
- The resultant temperature values have been removed from the "Sizing" results.
- Results given in CO2 instead of Carbon.
- Created an option to have extract fan only systems in Part L2.
- Now outputs "daylight factor" parameter in the setup tab of the excel spreadsheet created by running the daylight availability macro.
- On the CECM table of the output for Part L2, cells that contain total values have been replaced with cells that contain formulas that calculate totals. This way if the user alters the spreadsheet it will recalculate the total for them.
- In the PartL2 macro, fixed a problem with the boiler calculation that was caused by Excel rounding numbers